


DENISON HYDRAULICS

axial piston pump goldcup series

P24P/S E-mod., P30P/S B-mod.

service information



Publ. LTG 900022-A

0/98

DENISON Hydraulics



The product information, specifications, and descriptions contained in this publication have been compiled for the use and convenience of our customers from information furnished by the manufacturer; and we can not, and do not, accept any responsibility for the accuracy or correctness of any description, calculation, specification, or information contained herein. No such description, calculation, specification, or information regarding the products being sold has been made part of the basis of the bargain nor has same created or amounted to an express warranty that the products would conform thereto. We are selling the goods and merchandise illustrated and described on this publication on an "as is" basis, and disclaim any implied warranty, including any warranty of merchantability or warranty of fitness for any particular purpose whatsoever, with respect to the goods and merchandise sold. All manufacturer warranties shall be passed on to our customers, but we shall not be responsible for special, indirect, incidental, or consequential damages resulting from the use of any of the products or information contained or described on this publication. Further, we reserve the right to revise or otherwise make product improvements at any time without notification.

	PAGE
Introduction	1
Hydroconnections	1
Seal脂	1
Installation	1
Description	1
Mounting	1
• rear pump mounting	1
General information	1
Filling	1
Recommended fluids	1
• viscosity	1
• viscosity index	1
• temperature	1
• alternate fluids	1
Fluid cleanliness	1
Classification of solid contaminant classification system	1
Tightening	1
Service Information	1
Fault diagnosis	1
Start up procedures for demulsification	1
• trouble shooting	1
Assembly tool drawings T1, T2, T3, and T4	1
Disassembly procedures	1
• removal limits of wear parts	1
Assembly procedures	1
• figure 1: rear end bearing assembly	1
• figure 3: lower case, piston rod & rear seal	1
• figure 4: carrier and auxiliary drive shaft 24 series	1
• figure 4.1: carrier and auxiliary drive shaft 30 series	1
• figure 5: housing	1
• figure 6: housing, end cap, cover plate	1
• mechanical muffler	1
• figure 7: seal assembly	1
• carrier balance plate	1
• servo plate	1
• control cover	1
• figure 8: port block	1
• port block mounting	1
• figure 9: carrier breakdown - rear auxiliary pump 24 series	1
• carrier breakdown - rear auxiliary pump 30 series	1
• auxiliary pump and actuator	1
• figure 10: rear drive cylinder and shuttle valve	1
• rear drive assembly	1
• pilot valve	1
• shuttle valve	1
• figure 11: exploded view of shuttle valve and pilot valve extension	1
• shuttle valve hubplate	1
• shuttle valve mounting	1
• valve block assembly	1
• figure 12: valve block assembly	1
• valve block for servo valve	1
• figure 13: valve block for servo valve	1
• test procedure	1
• internal test procedure	1
Control test - refer to control service manual ST-AM031	1
Hydraulic circuit P24B0P	1
Hydraulic circuit P24B0S	1
Installation drawings	1
Welding code	1
Compliance & limitations	1

TECHNICAL CHARACTERISTICS

specification	term	Goldcup 24	Goldcup 30
*displacement at max. angle	ml/min. cm ³ /min.	24.8 533	30.8 501.4
*pressure: continuous	psi bar	5000 345	5000 345
*speed max. continuous: st. full stroke (pc.)		2100	1800
continuous DENISON HYDRAULICS to higher speeds:			
*flow: ports A or B	at 1500 rpm Max. at max. dep.	gpm l/min	189.7 504.6
	at 1800 rpm	gpm l/min	191.7 512.1
	at 2100 rpm	gpm l/min	223.6 600.6
static pump heads-disk / rev.			
	interv.	P24P 28.1	P30P 38.1
	cc/rev.	18.1	25.1
	interv.	P24S ^a 1.03	P30S ^a 1.03
	cc/rev.	17.1	17.1
*flow: auxiliary pump at 1800 rpm			
internal flow	gpm l/min	18.2 52.1	18.2 52.1
at 1800 rpm	gpm l/min	21.3 62.9	21.3 62.9
at 2100 rpm	gpm l/min	25.5 78.7	25.5 78.7
*flow: auxiliary pump at 1800 rpm ^b			
internal forward flow	gpm l/min	8.5 24.3	8.5 24.3
at 1800 rpm	gpm l/min	7.6 23.7	7.6 23.7
*flow: auxiliary pump at 1800 rpm ^c			
internal forward flow	gpm l/min	18.2 52.1	18.2 52.1
at 1800 rpm	gpm l/min	21.3 62.9	21.3 62.9
static pump servo pressure range	psi bar	P24P 340-640 29-44	P24S 380-730 34-54
*max. pressure with pressure in gpm & bar	bar	P30P 380-772 34-56	P30S 480-802 44-66
based on 0 bar 0 bar case pressure:			
*Aux. pump static pressure based on 0 bar 0 bar case pressure:	bar	P24P 180-225 12-18	P24S 330-370 23-28
*mounting	SAE	P30P 185-220 12-18	P30S 330-370 23-28
*drain valve torque	SAE	50-14 100	50-14 100
*weight	lbs kg	P24P 680 315	P24S 755 345
P30P 7.0 325		P30S 7.0 325	

^aOn P & Q discharge and oxidized oil filter
standard; other sizes available

^bNormal range provides servo flow and must be supercharged from external
implementing flow from external auxiliary pump

^cAt SAE 9220 or SAE 104-2 mounting pump may be used, with the corresponding
filter

Refer to page #2 for specifications.

SEAL KITS

Seal Kit P2430 complete (includes control seals)
 • same as seal kit (all)
 shaft seal (dt)
 shaft seal
 control seal kit (all - input & output)

See part number:
 S23-17038-BK
 see part number
 S23-00015-BK
 S23-17000-HK

Seal Kits for P24-30 Gold Cup Pumps:

CUP	MOD	SERIES	SHAFT TYPE	BOT	COMPLETE SEAL KIT	SHUTTLE	SHAFT SEAL KIT
24cm	E&B	E	2.1	R&L	S23-18006-BK	N/A	S23-17018-BK
		H			S23-18016-BK		S23-18032-BK
		X	7.8	R	S23-11514-BK		S23-18033-BK
		R			S23-17038-BK		S23-18034-BK
		P			S23-17039-BK		S23-18035-BK
		R			S23-18017-BK		S23-18036-BK
		R			S23-18018-BK		S23-18037-BK
		X			S23-18021-BK		S23-18038-BK
		X			S23-18028-BK		S23-18039-BK
24cm	E&B	Z	2.1	R&L	S23-17040-BK	S23-18088-BK	S23-17018-BK
		L			S23-18019-BK		S23-18032-BK
		Z	7.8	R	S23-17041-BK		S23-18034-BK
		S			S23-17042-BK		S23-18035-BK
		L	7.8	R	S23-18020-BK		S23-18036-BK
		L			S23-18021-BK		S23-18037-BK

Seal Kits for P24-30 Gold Cup Pumps With TDC Auxiliary Pumps:

CUP	MOD	SERIES	SHAFT TYPE	BOT	COMPLETE SEAL KIT	SHUTTLE	SHAFT SEAL KIT
24cm	E&B	S	2.1	R&L	S23-11600-BK	S23-18088-BK	S23-18018-BK
			7.8	R	S23-18080-BK		S23-18032-BK
			7.8	L	S23-18087-BK		S23-18033-BK

Note: Add -4 FOR STEEL -4 for ZZ (Rubber) or -3 for VITON if required.

The DENISON HYDRAULIC® Series 20 and 30 axial piston pumps feature advanced design concepts which combine power and provide for advanced pumping and control concepts. The instructions contained in this manual cover complete disassembly and reassembly of the unit. Before proceeding with the disassembly or reassembly of any unit, the manual should be studied in order to become familiar with proper tools and parts nomenclature.

DESCRIPTION

The use of a rocker cam to control the pump displacement provides a small package size, reduced weight, and speed control response. The control mechanism eliminates linkage and backlash inherent in typical stroke cylinder designs. Standard controls for the Series 20 units are rotary servo and compensator valves; the additional optional controls are also available.

MOUNTING

This pump is designed to operate in any position. The mounting hub and 4 bolt mounting flange are in full conformance with SAE standard. The pump shaft must be in alignment with the shaft of the prime mover. This should be checked with a dial indicator. The bearing pad or duplex bearing into which the fluid pump shaft must be concentric with the pump shaft to prevent bearing failure. The concentricity is particularly important if the shaft is rigidly connected to the prime mover without a flexible coupling.

REAR PUMP MOUNTING

Caution: P24.30S Only

Shaft seal on coupling shaft isolates internal pressurizing pressure from the external pump. At 100% load pump equivalent shaft sealing pressure, i.e., Newland equal to $72.3 \times$ operating pressure bar, will be exerted on the shaft of the rear mounted pump. Shaft bearing capacity of the external pump must be considered when specifying external pump.

In any application it is advisable to check the alignment of the pump shaft to the prime mover to avoid side-loading the pump shaft bearing and bending of the shaft.

The maximum allowable axial fit of the pump shaft and prime mover is 0.006 inch (0.15 mm T.I.B. Total Indicator Reading).

The maximum allowable radial misalignment is $\pm 0.02^\circ$ (0.05°) or 0.002 mm per mm radius.

SHAFT INFORMATION

Splined: The coupling interface must be lubricated DENISON HYDRAULIC® recommended non-detergent grease. The female coupling should be honed to 27-45 Ra and must conform to SAE J406B (1971) class 1 but not less fit.

Keyed: High strength hardened keys must be used. Replacement keys must be hardened to 27-34 Rc. The key collets must be chamfered 0.030"-0.040" (0.75-1mm) at 45° to clear all flats exist in the keyway.

Note: Do not impact coupling face onto the shaft. After lock, use #15 file provided in the end of the shaft.

Both types of shafts will accept a shoulder of 1000 lbs. loading at the center of the spline area, with a B10 life of 2560 hours at 1800 rpm or 1185 hours at 3000 rpm.

PIPING

Caution: Internal fluid must be the part of the pump.

The maximum case pressure is 17.6 psi (1.2 bar) or 1000 psi (68.9 bar) internal. When connecting case to the reservoir make sure piping does not rise above highest point of the pump before passing to the reservoir. If not, install a 6 psi (0.3 bar) case pressure check valve to be certain the case is filled with oil at all times.

Note: High case pressure will result in required shaft bearing ± 10 Hz. The case leakage line must be of sufficient size to prevent tank pressure in excess of 7.5 psi (0.5 bar) and returned to the reservoir below the surface of the oil after from the supply or suction oil line lines. Whether pipe, tubing, or hose must be proportional to size. In case of low flow through the pump. We recommend 20 ft (6.09 m) max per second for main flow and 4 ft (1.4 m) max. flow per second for suction lines. The case drain flow can exceed the steady state required for causing movement. Size the line for 10 ft (3.05 m) max per second. Pressure rating of piping hoses must be calculated for service duty required. An undersize line will prevent the pump from operating at full rated speed. An undersized outlet line will create back pressure and cause heat generation with improper operation. Flexible hoses must be used to reduce the pump to system piping. If rigid piping is used, the working piping must be accurate to eliminate strain on the pump front block or at the fluid connections. Sharp bends in tubing must be eliminated wherever possible. All system piping must be cleaned with solvent or equivalent before installing pump. Make sure the entire hydraulic system is free of dirt and debris, remove foreign material. Filling with large temporary high pressure loop filter is recommended. Piping must be cleaned so that the fluid cleanliness specified below is maintained.

Caution: Do not use galvanized pipe. Galvanized coating can break off with continued use.

The fluid recommended for use in these pumps has a petroleum base and inhibiting agents which provide oxidation inhibition and anti-seize, anti-wear and de-seizing properties as described in DENISON HYDRAULICS standard HF-1. When anti-wear additive fluids are specified see DENISON HYDRAULICS standard HF-4.

VISCOSITY

Max. at full power - 750 SUS 160°C
 (at low pressure, low flow, and if possible, low speed)
 Max. at full power - 750 SUS 160°C
 Optimum for max life - 140 SUS 30°C
 Minimum at full power - 50 SUS 16°C

VISCOSITY INDEX

90 VI minimum. Higher values extend the range of operating temperature but may reduce the service life of the fluid.

TEMPERATURE

Generally, the viscosity characteristics of the fluid itself. Because high temperatures degrade seals, reduce the service life of the fluid and create hazards, fluid temperatures should not exceed 180°F/82°C at the case drain.

ALTERNATE FLUIDS:

Some applications require fire-resistant fluids. They will give good service if the system is originally designed for them. Permissible fire-resistant fluids include:

Type	DENISON HYDRAULICS Standard:
Water-in-oil layered emulsions	HF-3
Water-glycol solutions	HF-4
Phosphate esters	HF-5

Consult DENISON HYDRAULICS for design requirements and compatibility limitations for service with the class of fluids.

See DENISON HYDRAULICS bulletin 500-4M02 for more information.

FLUID CLEANLINESS

Fluid must be cleaned before and continuously during operation, by filters that maintain a cleanliness level of NAS 1838 class 6 (class 9 for 15 micrometres). This approximately corresponds to ISO 4406. The fluid level cleanliness can usually be accomplished by the effective use of 10 micron filters. Better cleanliness levels will significantly extend the life of the components. As contaminant generation may vary with each application, each must be analyzed to determine proper filtration to maintain the required cleanliness level.

COMPARISON OF SOLID CONTAMINATION CLASSIFICATION SYSTEM

NATIONAL AERONAUTICS STANDARD (NAS) 1630

Particulate size	Class													
	00	0	1	2	3	4	5	6	7	8	9	10	11	12
5-15 micrometres	138	260	300	4000	3000	4000	3000	4000	32000	84000	128000	256000	512000	1024000
15-30 micrometres	22	44	69	175	388	712	1425	2850	5700	11400	22800	45600	91200	182400
30-50 micrometres	4	8	15	32	68	135	272	544	1088	2176	4352	8704	17408	34816
50-100 micrometres	4	8	8	8	11	20	40	80	160	320	640	1280	2560	5120
100-150 micrometres	0	0	1	1	2	4	8	16	32	64	128	256	512	1024
150-250 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
250-500 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500-1000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000-2000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000-5000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
5000-10000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
10000-20000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
20000-50000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
50000-100000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
100000-200000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
200000-500000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500000-1000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000000-2000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000000-5000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
5000000-10000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
10000000-20000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
20000000-50000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
50000000-100000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
100000000-200000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
200000000-500000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500000000-1000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000000000-2000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000000000-5000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
5000000000-10000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
10000000000-20000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
20000000000-50000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
50000000000-100000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
100000000000-200000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
200000000000-500000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500000000000-1000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000000000000-2000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000000000000-5000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
5000000000000-10000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
100000000000000-200000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
200000000000000-500000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500000000000000-1000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000000000000000-2000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000000000000000-5000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
5000000000000000-10000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
10000000000000000-20000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
20000000000000000-50000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
50000000000000000-100000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
100000000000000000-200000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
200000000000000000-500000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
500000000000000000-1000000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
1000000000000000000-2000000000000000000 micrometres	0.0001	0.0002	0.0003	0.0005	0.0008	0.0012	0.0024	0.0048	0.0096	0.0192	0.0384	0.0768	0.1536	0.3072
2000000000000000000-5000000000000000000 micrometres	0.0001	0.0002</td												

It is essential to make certain that the case (pump housing) is full of fluid before the unit is turned on. Fill until expansion limit is set.

Always fill to the highest available point. Remove堵堵 or screw and allow the oil to escape through this port.

Recommended fill points:

Mounting bracket with shutoff D1 or D2 (drain) port in location
With DG2 port in mounting flange (new units) or
one of the upper screws which attach the cover. See installation drawing.

Vertical, wait down 11° from horizontal
from tank to the side

D1 or D2 (drain) port in location

With DG1 (case drain) port in port block

SERVICE INFORMATION

These hydraulic products are designed to give long reliable service when properly applied and their systems properly maintained. These general instructions apply to two-speed systems. Specific instructions for particular equipment can be developed from basic.

MAINTENANCE

The pump is self-aligning and preventative maintenance is limited to keeping system fluid clean by changing filter frequently. Keep all fittings and covers tight. Do not operate at pressures and speeds in excess of the recommended limit. If the pump does not operate properly, check the troubleshooting chart before attempting to overhaul the unit. Overhauling may be accomplished by referring to the disassembly, rework lists of wear parts, and assembly procedures.

START UP PROCEDURES FOR NEW INSTALLATIONS

- Read instructions and the instruction manual. Identify components and their function.
- Visually inspect components and lines for possible damage.
- Check reservoir for cleanliness and drain and clean as required.
- Check fluid level and filter, replace with filtered fluid at least as clean as that recommended. **Fill pump case with clean oil prior to starting.**
- Check alignment of drive.
- Check switches and controls. If installed in circuit.
- Reduce pressure settings of relief valves or compensator. Make sure accurate pressure readings can be made at appropriate places.
- If handles are installed in system, check for activation.
- Start pump drive first by locking drive motor. Make sure pump and motor fit properly.

Caution: Ensure that the servo valve with pump powers up at startup. This is important on a newly installed application or one that allows the servo/reverser pump to lose its prime during shutdown. Failure to reseat the prime can damage the main pump or the servo/reverser pump.


- Bleed system air. Recheck fluid level.
- Cycle unloading manifold at low pressure and observe activation (at low speed if possible).
- Increase pressure settings gradually in steps. Check for leaks in all lines, especially pump and motor inlet lines.
- Make correct pressure adjustments.
- Gradually increase speed. Be alert for trouble as indicated by changes in sounds, vibration, blocks and line heat.
- Considerable operational

Component problems and causal problems are often interrelated. An improper causal problem will appear unless first will cause failure of a causal component within it. The component failure is the effect; not the cause of the problem. This general guide is offered to help in locating and eliminating the cause of the problems by attacking the effect.

effect of trouble	possible cause	fault which needs remedy
noisy pump	air in fluid	leak in suction line low fluid level incorrect fluid return lines above fluid level gas leak from compressor compressor pressure drop in the line from a pressurized reservoir suction line diameter too small
vibration in pump or motor rotating group	fluid too cold fluid too viscous fluid too heavy sight speed too high section lines too small suction line collapsed suction strainer too small or foreign section strainer too dirty operating altitude too high location/replacement incorrect (too low) replaced/motor flow too small for dynamic connection	
misaligned shaft	faulty installation distortion in mounting axial clearance faulty coupling excessive overhung load	
mechanical fault	incorrect or loose lockwashers or locknuts loose bolts incorrect port plate selection or index embeded or worn parts in the displacement control	
incorrect barrel ports and bore rate	in fluid deviation	see above see above
high heat in pump & motor	excessive load contamination plugged in-line filter	reduce pressure settings reduce speed improper filter maintenance incorrect oil introduction of dirty fluid to system reservoir openings improper reservoir treated improper line replacement
improper heat		incorrect limit of maximum operating temperature range
		breakdown of fluid with time/temperature/bearing effect incorrect additives in new fluid destruction of additive effectiveness with chemical aging
incorrect repair		incorrect part incorrect procedures, dimensions, finished
incorrect water in fluid		contamination fault, breathes air heat exchanger leakage faulty clean-up practice water in meter up fluid


effect of trouble	possible cause	fault which needs remedy
pressure drops	clogging back pressure relief valve	mechanical breakdown
	worn relief valve	rebuild/replace
	worn compaction sensor	rebuild/replace
	slow response in servo valves	replace or relocate
	servo pressure too low to maintain line control	reduce pressure and check pressure drop through servo filter
	excessive decompression energy losses	improve decompression control
	excessive line capacitance (line volume, line stretch, accumulation effects)	reduce line size or lengths; eliminate hose
	barrel blow-off	re-check pump hold-down isolating ground circuit procedure
leaking oil/wax	excessive pump or motor leak rate	re-think cross-drain flow and rework as required fluid too fast
	valve leak	over-tighten assembly, port limiting
	compaction	set tool flight compensated to set tool compensation capability/correct fly-back pressure w/o tool parts worn/parts
	power too large for tool heads	select smaller pump displacement
heat exchange	heat exchanger too little heat waste too hot	heat exchanger too little heat waste too hot
		efficiency reduced by small or small density difference hydraulic fluid flow
reservoir	too little fluid	check tank level
	contaminated air in tank	improper fittings
		monitoring air bubbles that prevent heat rejection heat pickup from ambient equipment

T2. Börrel HLF (auktioniert von)




Te Material - paid 2001 street

T3 Replenishing and serving (remove tool)



ITEM	DESCRIPTION	PART NO.	QTY
1	1/2" x 2' Angle - 1/8" Steel Plate - 2 x 486 Greifmeyer Co.		1
2	1/2" x 3' O/D - 4140 Steel (12" Incls = 76.2mm)		1
3	1/2" Tension O/D x 2' (50mm) - 1/16" Steel HUN-132		1

T4 Shell script installation tool - no adapter



The instructions contained in this section cover a complete teardown of the stayed pump. Instructions only call for necessary for replace or repair any worn parts.

DISASSEMBLY

CAUTION: On C4 series units read barrel holddown prior to removal of starf seal or barrel shaft. Failure to follow this procedure may result in pump failure.

NOTE: The bar main assembly (1) (Figure 9) has number 450 (16-6102 Rev). These bolts should be loosened prior to removing unit for disassembly.

Position pump unit so that the valve block assembly (11/12) (Figure 10) is on top. A bench or simply suitable surface capable of supporting unit should be used. Disassembly area should be clean.

VALVE BLOCK

See Figure 10: Remove the eight hex head cap screws (13) and the valve block assembly (10) from the port block.

See Figure 11: Remove the four hex head cap screws (15) and four end cap screws (16) and lift the entire block assembly (10) from the port block.

(Refer to 7-23)

See Figure 12: Remove plug (20), (21) and pin (21). Remove the B-32 bolt from the bottom of block (11) to remove filter assembly (14). Do not remove the check valves (21).

Remove housing (18), o-ring (3), piston seal (19), o-ring (14), o-ring (8), nut (2) and socket (16) as a unit.

Remove spring (12) and sleeve (13). Remove seal (5) and o-ring (4).

NOTE: See file note for new O-rings. Use 1/2" six point socket wrench.

Remove plug (22) and replaceing relief valve (38).

Remove o-rings (37), (40) and (41). Remove four screws (43) and remove left side plate (42). Do not remove solenoid (36) unless replacements are needed.

Remove gasket (29) and seals (27) and (28). Remove poppet (30), (31) and spring (32), (33), (35) and retainer (34).

Inspect orifices (1) Verify to make they are open. Do not remove unless damage or clogging is apparent.

CONTROL COVERS

See Figure 7: Remove the four screws (13) with the washers (12) from the side cover (11) and remove the front control assembly.

NOTE: The middle washer must be replaced in assembly.

Remove the four screws (13) with the washers (12) from the side cover (11).

Remove the two screws (11) and sleeve (16) and remove the balance plate (9).

See Figure 6: Remove the two screws (8) and remove the balance plate (7).

NOTE: Poppet's nuts will require removing the shuttle valve assembly and external valve pump assembly and lifting.

Removal of External Aux. Pump Shuttle Valve, Monoflo Adapter and Internal Aux. Pump:

See Figure 10: Remove fitting between external pump and main pump.

Remove two screws holding pump. Remove pump from rear of the mounting plate.

Remove two screws holding coupler (19) in place. Remove shuttle block.

Remove two screws M8 holding an aux. adapter (17) and auxiliary adapter and o-rings (13) & (16).

Remove six allen (7) and mounting bracket (8), coupling (14), and gasket (22).

On non-rear drive units, Remove plug (9) and fitting (6).

Remove eight screws (11) and end cap (16), two set screws (15) and o-rings (4) and (3).

Remove auxiliary pump assembly (2).

(continued)

124 *barrel hold-down*

NOTE: This part contains a cartridge assembly and must be handled with care. Do not drop or impact.

Remove sealing washer (1).

See Figure 3. Remove hold-down lock retainer ring (2) (use internal extraction plate).

See Figure 4. Removal four screws (1) and two screws (8). **NOTE:** There is a risk that the barrel hold-down will lift the port block approximately 1.9" (5 cm) at release.

Carefully lift and remove port block (2) and port plate (4). **CAUTION:** The port plate may stick to the barrel tube because of oil film. Do not allow the port plate to fall and become damaged.

See Figure 5. Remove the two plates (2) and face plate pin (1) from the face of the barrel assembly.

See Figure 6. Remove hold-down adjusting screw lock (7) set an 18° hex type screwdriver, with the handle ground down to clear hold-down shaft.

See Figure 7. Lock nut and lock nut forming.

See Figure 8.1. Use special tool (12), slip over auxiliary shaft (2) and extract dowels into hold-down adjusting screw (6). Loosen lock nut do not remove.

See Figure 8.2. Remove two bolts (8) bolting barrel and flange together.

See Figure 9. Push tubes (4) out of housing slots and toward barrel to avoid bending or damage them.

See Figure 10. Lift housing (4) out tubes and barrel assembly and remove. Mounting bracket must be driven from housing due to tight fit.

NOTE: Do not damage guide faces in this process. Do not remove the remaining screws of bearing from the barrel unless bearing is damaged and replacement is necessary.

Barrel assembly can be reassembled by lifting with auxiliary shaft. The piston will remain with the barrel assembly. These parts are precision threaded and must be handled with extreme care.

See Figure 11. Using special tool (12), hold-down assembly can be removed from barrel. Remove adjusting screw (6), spring (5), retainer (4), cylinder oil seal (1) and barrel shaft (2).

See Figure 12. Removal four screws (1) and two screws (8). **NOTE:** There is a risk that the barrel hold-down will lift the port block approximately 1.9" (5 cm) at release.

Carefully lift and remove port block (2) and port plate (4).

CAUTION: The port plate may stick to the barrel tube because of oil film. Do not allow the port plate to fall and become damaged.

See Figure 13. Remove the two plates (2) and face plate pin (1) from the face of the barrel assembly.

See Figure 14.1. Loosen six screws, gradually in alternating sequence.

CAUTION: Hold-down is under pre-tension. Do not remove screws completely.

Insert three #10-32 screws into the three #10-32 threaded holes. Alternately, tighten three #10-32 screws until the threaded retainer releases. Do not force counterclockwise when tighten.

See Figure 15. Lock nut and lock nut forming.

See Figure 16.1. Use special tool (12), slip over auxiliary shaft (2) and extract dowels into hold-down adjusting screw (6). Loosen lock nut do not remove.

See Figure 16.2. Remove two bolts (8) bolting barrel and flange together.

See Figure 3. Pull tubes (#) out of housing slot and toward handle, or crimp band or clamp them.

See Figure 6. Lift housing (#) over tubes until handle assembly has been removed. Mounting flanges must be driven from the housing due to tight fit.

NOTE: Do not damage gasket faces in this process. Do not remove the retaining screw or bearing from the housing unless bearing is damaged and replacement is necessary.

Bore assembly can be removed by lifting with auxiliary shaft. Tie plates will remain with the bore assembly. These parts are precision finished and must be handled with extreme care!

PORT BLOCK

See Figure 8. Remove the check valve assembly (#) from the port block.

Remove plug (#) and (#10).

Remove lock screw (#), lock washer (#), check ring (#) and spring (#).

DRIVE SHAFT

See Figure 7. **NOTE:** Pump case must be on center 3/8" angle before removing shaft.

Remove burr set(s) (#), seal retainer (#), bracket (#), and stationary port shaft seal assembly (#). Refer to view of item (#1).

Remove the piston ring and the remainder of the shaft seal from the shaft.

Remove shaft and bearing assembly (#).

ROCKER CAM AND CONTROL STROKING ASSEMBLY

See Figure 9. Remove pressure feed lines (#) from the cradle. DO NOT BEND THESE LINES! Discard all part lines.

Remove the rocker cam assembly from the mounting flange by carefully lifting mounting flange off of sleeve using a 1/4-20 threaded rod to a pulley. Remove plug (#) with o-ring (#) and then release sleeve (#) attaching cradle mounting flange.

Position rocker cam assembly in a clear space with the control lines (#) in horizontal position and oriented at the top.

See Figure 10. Lift off the snap (#1) and blade (#6) as indicated. These items will determine positioning of parts during assembly.

Position the assembly in a upright position on the flat surface of the cradle.

Remove the retaining ring (#11), thrust washer (#2), detonated snap assembly (#3) and snap plate (#5) from the rocker arm (#1).

Remove the tool screws (#11) and tool screws (#12) from the control chamber covers (#16) and (#18L).

Remove the control chambers (#14). Remove the seals (#17), four steel bolts (#18) and cover pins (#15).

Remove the screw (#19), valve seat cartridge (#23), holdown plates (#22) from the rocker arm (#1).

Remove the rocker cam from the cradle (#11).

REWORK LIMITS OF WEAR PARTS

Wear Part	Max. rework from original dimension	Min. dimension after rework
piston face	0.015" / 0.254 mm	0.732" / 18.57 mm
slide retainer plate	0.005" / 0.127 mm	0.984" / 2.50 mm
piston slide face/pocket	0.010" / 0.254 mm	0.010" / 0.254 mm
snap plate face	0.010" / 0.254 mm	0.365" / 9.22 mm
lube plate	none	reduce

No rework allowed on 30°W piston slide face

IMPORTANT:

The bolt plate thickness must be 8 millimetres. 0203 micrometer with jaws, 1st within 0.00005", 0.0013 mm and parallel within 0.001", 0.0254 mm total indicator reading.

The sleeve plate washer thickness must be 9 millimetres; 0122 micrometer, 1st within 0.0005", 0.0127 mm and parallel to the backplane within 0.001", 0.0254 mm total indicator reading.

The shoe retainer wear base thickness must be 9.2 micrometers; 0819 micrometer and 1st within 0.0009", 0.0127 mm. Must not be hollow.

The piston shoes wear base finish must be 5.0 micrometers; 0782 micrometer and must be parallel to the rear surface, all three shoe thicknesses to be within 0.001", 0.0254 mm after assembly. The maximum permissible clearance between axial bores is 0.010", 0.254 mm.

The special retaining ring service kit S23-12629 may be required to control shoe hold-down clearance.

ASSEMBLY PROCEDURE

All parts must be inspected and be free of material defects, dirt, scratches or any foreign material.

All parts must be cleaned with a suitable cleaning solvent and all holes and passages blown out with dry clean compressed air.

After cleaning and inspection, all parts must be covered with a light film of oil and protected from dust and moisture. Excessive handling after fit will cause damage to assembly.

During assembly, stepped and ground surfaces must be lubricated with clean oil and protected from noise or surface damage.

DRIVE SHAFT AND BEARING ASSEMBLY




Figure 2

323-12478 is for RH CW rotation pump with 18T suffix input control oil right side.
 323-12479 is for LH CCW rotation pump with 19T suffix input control oil right side.
 323-12476 is for RH CCW rotation pump with 2A suffix input control oil left side.
 323-12477 is for LH CCW rotation pump with 2B suffix input control oil right side.
 *Viewed from the front of pump with valve block in top 12 o'clock position.

ROCKER CAM, PISTON SHOES & RETAINER

PARTS LIST FOR FIGURE 2

item	description	part no.	quantity
1	returning tube-welded tube		1
2	089-087 2.29x2.21mm thick with yellow dot	089-21146	1
3	081-085 2.39x2.18mm thick with green dot	081-71117	1
4	081-083 2.159x2.08mm thick with white dot	081-91130	1
5	083-081 2.108x2.057mm thick with red dot	083-71118	1
6	081-079 2.105x2.007mm thick with blue dot	081-89746	1
7	returning tube assembly	323-12229	1
8	flange washer	083-58605	1
9	socket head cap screw	259-13180	2
10	retainer-platen-shoe assy, P24	313-44470	1
11	retainer-platen-shoe assy, P30	323-12684	1
12	cam plate	083-81283	1
13	servo plate	083-71112	1
14	camber screw	083-70619	2
15	camber lock clip assy	253-45023	2
16	camber head cap screw	358-10120	2
17	servo plate	083-53877	1
18	hex. head cap screw 1.2-18	306-40174	4
19	hex. head lock screw 2.5-18	306-40035	4
20	right side chamber cover, CW	083-71598	1
21	right side chamber cover, CCW	083-71595	1
22	left side chamber cover, CCW	083-71596	1
23	left side chamber cover, CW	083-71597	1
24	left side chamber cover, CCW	083-71593	1
25	control chamber	083-71137	2
26	control seal	254-22428	4
27	steel ball	231-06001	12
28	control chamber seal	896-25048	12
29	rocker cam	083-81141	1
30	ring	891-00805	12
31	hexagon rocker plug	481-25027	12
32	rocker stem	083-12482	1
33	Hold down nuts	083-70819	12
34	base seal bolt tool	see below	12
35a	base seal bolt tool plate	083-71725	1
35b	base seal	083-71714	12
36	o-rings	691-00129	12
37	base gaskets	083-71722	12
38	spacers		12
39	2500-1495 6.35x8.337 mm pipe	083-29808	1
40	2510-2510 6.35x8.35 mm yellow	083-29805	1
41	2530-2526 6.43x6.41 mm green	083-29864	1
42	overdrive tube P24	083-71721	1
43	overdrive tube P30	083-57983	1
44	hex. socket set screw	312-00032	12

See figure 2. Position the cradle (18) on a clean surface with the large flat side down.

Lightly oil curved surface of cradle. Position rocker case (21) on the cradle, aligning "match marks made during disassembly".

Place O-ring (23a) on valve spacer (23d) and insert in the valve seat (23c).

Select spacer (23c) such that when installed in the seat slot there is .000-.015" (.000-.038 mm) clearance between spacer and valve stem. There are three different spacers available for this application. Part number is marked: 0.2500-0.2495" B85-0.337 mm color blue; 0.2515-0.2510" B39-0.36 mm color yellow; 0.2530-0.2525" B43-5.41 mm color green.

Install assembled valve seal cartridge in slotted boss on side of rocker case as indicated. Use a flat metal tool and lightly tap assembly in position after rocker case is positioned in cradle base.

Install rocker head cap screw (19) into case, seating through valve assembly. Torque to 30 lbs-ft, 40.7 Nm.

Install the four nylon hold-down covers (22) in the slots on each side of the valve seal cartridge (23).

Position both control chambers (14) on a clean surface with seal groove facing up.

Insert one steel ball (16) in each of the counterbored holes at the end of each of the seal grooves. Coat ball in seal.

Install beads (117) in grooves of the control chambers.

NOTE: The expanded size of the seal will be pushed into the groove until the end of the seal covers the steel balls.

Install the assembled control chamber (14) over the seal cartridges by lifting the chamber until they sit over the valve seal cartridges. Then rotate in the opposite direction until the 8.81 dowel pin holes in the chambers align with the dowel pin holes in the rocker heads (18). Install dowel pins FIRST through the control chambers and into the cradle.

Install chamber covers (18a) and (18b) on the control chambers (14). The covers must be installed with the service tube (24) holes at the top. Note the marks made during disassembly to indicate the top of the rocker case and cradle.

NOTE: Two sets of control chamber covers are supplied. The set marked CW must be attached to the right hand lever arm pump and the set marked CCW must be attached to the left hand lever arm pump. Rotation is determined from the back end of the rod and.

Install two 1/2-13 hex head cap screws (11) in each side. Torque to 7.8 lbs-ft, 10.175 Nm.

Install two 3/8-16 hex head cap screws (12) in each side. Torque to 3.0 lbs-ft, 40.7 Nm.

Install bearing (19) and hex cover (20) in each chamber system.

Install override line (24) in holes in each cover. These lines must be a tight fit. If they are loose, the ends may be expanded with a tapered pliers. Tie the lines in place with a plastic tie.

Thread two control rings (7) into servo stem (8).

Determine the proper location of the servo plate assembly. Looking at the protecting center post of the rocker case with the example two holes at the top, "some A" mount the servo plates on right hand side or B on the left hand side.

Thread two 1/2-24 bolts (10) and a screw (9) into the servo stem until the rocker case (12). Torque to 4.0 lbs-ft, 5.7 Nm.

PISTON AND SHOE ASSEMBLY

Install lever plate (10) to stem (2) with two #10-24 socket head screws (8). Torque = 10-13 Nm. Install lock washer (9) in lever plate. Torque = 25 lbs-in / 2.8 Nm.

NOTE: The advance plate cannot be assembled to the rocker arm until after the housing assembly installation has been completed. See figure 7.

Install (see fig. 5) over center piston rod (2).

Insert piston and shoes into stabilizer rod/metal actuator assembly (4) (add crepe plate).

Install (1) lock washer (2) over center post of stem and against shoe retainer. Grooved side of washer must face shoe retainer.

Install the thickest retaining ring (11) that will fit in the groove of the rocker arm center post. Width will allow maximum clearance of 0.025-0.035", 0.05-0.13 mm between the shoe plate and the post. To check this clearance, run the piston and fit with light segmentation retained sheet thickness gauge. If this clearance is not correct, select the appropriate retaining ring and repeat the checking procedure.

NOTE: If metallic thickness gauge is used, caution should be exercised not to scratch surface. There are five different retaining rings available for this tolerance. Each retaining ring is marked 0.081-0.093", 2.03-2.24 mm thick blue dot, 0.083-0.091" 2.08-2.05 mm thick red dot, 0.085-0.093", 2.159-2.108 mm thick white dot, 0.087-0.086" 2.18-2.15 mm thick green band, 0.088-0.097", 2.19-2.21 mm thick yellow dot. The piston and shoe assembly must be held to within 0.001" in height.

See figure 3. Install two elbow fittings (3) into the threaded holes in the cradle.

NOTE: Check the feed tubes (4) and override tubes (2) by fitting them into the correct port holes before assembling to the striking assembly (5). They must be correct; please fit them so they key off a small shoulder (2) on the system housing. If they fit loose or are damaged they must be replaced.

Install pressure feed tubes (4) to elbow fittings (3). Tighten the connections with wrench.

Position the mounting flange (7) with the larger open end facing up and install two bowel pins (6) in the cradle mounting surface and the 3/8" x 9.5mm diameter screw (10) in the outer edge of the flange.

Install the motor/gear/damper assembly (5) over the bowel pins (6) in the mounting flange.

NOTE: Pressure feed tube (4) is on the same side of mounting flange as the main air line. The 3/8"-0.5-mm diameter bowel pin (10).

With pins and screw installed, flip mounting flange (7) upside down and secure with two lock cap screws (9). Torque to 50 lbs-ft / 67.8 Nm.

Install plug (11) with O-ring (8) into one 1/4" tap screw (9) hole. Be sure tapped hole in plug (11) is visible after installation. This is used for removal.

Install plug (12) with O-ring (13).

Install shaft assembly.

See figure 7. Shaft and bearing assembly (1) either splined or keyed as specified by inserting shaft through bores. A few light taps are required on the outer race to completely engage and seat bearing.

NOTE: Do not tap on end of shaft. Hit on the bearing outer race only.

**MOUNTING FLANGE,
CAM & CRADLE BARREL &
AUXILIARY SHAFT ASSEMBLY**




FIGURE 6

AUXILIARY SHAFT ASSEMBLY
(continued)
PARTS LIST FOR FIGURE 3

item	description	part no.	quantity
1	barrel & sleeve assembly	see fig. 4 or 41	1
2	wear plate (item 23)	see fig. 2	2
3	halls elbow	473-15041	2
4	lube assembly P24	S13-44469	2
5	lube assembly P30	S13-12172	2
6	locked cam & lockring assembly	see fig. 12	1
7	power pin	324-24028	2
8	mounting torque	029-91137	1
9	cam	01-00111	2
10	screws, lock	388-16260	2
11	power pin	324-22416	1
12	ring	022-67-173	2
13	plug	488-25031	3
14	o-ring	691-00204	3

Return the mounted flange to an upright position and tilt the rocker arm to either extreme attitude of the cradle.

Position the cam assembly (1) directly over the pinhole. Starting with the uppermost pin, guide them direct into the barrel holes.

NOTE: Support the barrel until the shaft is fitted tightly (do not hold by the barrel itself) and fully engage the lower shaft splines. Now the holdown screw can be tightened without any load against it.

**BARREL AND AUXILIARY
DRIVE SHAFT 24 SERIES**

See Figure 4: Install auxiliary shaft (2) large spline end first into counterbore in face of barrel spline.

Install spherical seal (3) onto sleeve bore (see fig. 1) into counterbore in face of barrel.

Install spring retainer (4) socket side down (no countersink). Install a pin (5) endfirst, against spring retainer.

Thread holdown adjusting screw (6) into counterbore approximately four threads.

Turn barrel vertically and engage front shaft splines with the barrel splines (driving home holdown at same time).

Thread holdown adjusting screw (6) into counterbore until it is flush to 0.000" (±.002 mm maximum) from base face.

PARTS LIST FOR FIGURE 4 (P24)

item	description	part no.	quantity
1	barrel & sleeve assembly	S23-12381	1
2	auxiliary drive shaft	033-57267	1
3	led through sleeve		
4	auxiliary drive shaft sleeve	SAE-B=323-17444-DK	1
5	(through sleeve)	SAE-BB=323-17448-DK	1
6		SAE-C=323-17448-DK	1
7	spherical seal	029-57-137	2
8	spring retainer	029-57-136	1
9	spring	029-57-136	1
10	holdown adjusting screw	022-67-139	1
11	holdown nut, screw lock	029-57-244	1
12	holdown bolt retaining ring	022-67-289	1




FIGURE 4

ASSEMBLY PROCEDURE




FIGURE 4.1

HOUSING ASSEMBLY

See figure 5.1. Install auxiliary shaft (2) through sleeve and front hub counterbored into barrel and engage barrel splines.

Slide hold-down spring assembly (3) onto shaft (2). Install spring retainer (5) into both faces.

Thread hold-down screw assembly (4) into barrel sleeve to engage approximately four threads.

Tilt barrel vertically and engage front hub flange with the barrel sleeve allowing barrel to drop in place.

Thread hold-down screw assembly (4) into counterbore nut (1) (25 mm dia) 5 mm below barrel flange.

PARTS LIST FOR FIGURE 4.1 (P30)

item	description	part no.	quantity	notes
1	barrel 3 sleeve assembly	323-12470	1	
2	auxiliary drive shaft	023-91188	1	
3	through drive			
	auxiliary drive shaft & coupling (through drive)	SAE-B-323-17445-OK		
		SAE-B-323-17449-OK		
		SAE-C-323-17447-OK	1	
		SAE-D-323-17451-OK	1	
4	hold-down spring	026-717-13	5	
5	spring retainer	023-91136	1	
6	barrel hold-down sleeve assembly	323-12411	1	

See figure 5 Clean housing (1) and position on a flat surface with the large open end (2).

Apply Loctite® primer grade "T" & Lubrite retaining compound #309 per A/P 01433 to bearing (3), & bearing bore of housing. Immediately align & press bearing into housing (2) with a smooth steady force until seated. Install socket head cap screw (3) with washer (4). Typical two places. Torque to 30 lbs-ft: 40.8 Nm.

Insert two power pins (5) in the right holes in the bottom cover plate. Repeat step above on the opposite side of the housing.

Install O-ring (6) and plug (7) in the bottom of housing.

PARTS LIST FOR FIGURE 5

item	description	part no.	quantity
1	housing	023-67150	1
2	bearing	M323-92401	
3	bearing	M323-92400	1
4	screw, socket head	#32-11000	2
5	power pin	323-91607	4
6	O-ring	323-92370	1
7	plug	323-92379	1
8	washer 1132-6745 mm steel	323-10001	2




Figure 5

ASSEMBLY PROCEDURE

See figure 6. Insert new gasket (3) over the dowel pin in the housing face. Do not use gasket compound.

Insert two setscrew lock cap screws (4) through holes in housing stem (1). Attach housing stem to housing control assembly. Torque to 70 lbf-in, 33 Nm.

Install the housing assembly (4) over the main/auxiliary stem assembly. Carefully guide the assembly into the housing face. Insert feed tube items 2 and 4 (Figure 3) through the housing assembly. Position the pressure feed tube in the slot in the housing face.

NOTE: Lightly force the pressure feed tubes down and down into the housing assembly. Do not bend or crimp the tubes enough so that they must be pulled up a little to snap into the housing slots. This will hold them in position for assembling the port block to the housing.

Insert two setscrew lock cap screws (5) through mounting flange and into housing. Torque to 100 lbf-in, 45.6 Nm. These must be fully torqued after initial torque and before

install face plate pins (1) in the holes predrilled in the cover face.

Apply clean, heavy grease to the surface of the barrel and install the face plate (2) over the face plate pins. The surface must be completely free of scratches, dust, dirt, paint, excessive leakage, surface pits, and any other material that might stick to the face plate.

CAUTION: The face plate has a black baked-on coating on top of bronze which is bonded to a steel backing. Lightly sand the edge of the plate to identify the bronze-coated side. The bronze side should go toward the port plate.

PARTS LIST FOR FIGURE 6

item	description	part no.	quantity
1	face plate pins	033-59747	3
2	barrel face plate P24	033-71745	1
3	barrel face plate P30	033-67571	1
4	housing spacer	033-91192	1
5	housing assembly	see fig. 3	1
6	hex lock screws	305-40003	2
7	sawndown screws	35P-10120	12
8	balance stem	033-71774	11





FIGURE 6

MECHANICAL SHAFT SEAL ASSEMBLY PROCEDURE



CAUTION: When installing a new mechanical shaft seal, exercise care to insure that all of the parts fit together properly. This is particularly important if the seal was once assembled and disassembled for some reason. If the rubber boot item 4, grip the seal until it does not slide on the shaft, and it disengaged from the spring item 5, can damage the shell item 6 from the hand, item 6, so that they do not engage properly when reassembled. Be sure the shell and the lip on the probe is engaged before reassembling the seal and move, engaged during assembly.

NOTE: Re-lubricating shaft seal is not recommended practice.

NOTE: Lubricate seal and shaft with clean oil, vegetable fluid or the same type that will be used in the system.

See figure 7.

NOTE 24 series only - to replace shaft seal only:

Remove unit for disassembly.

Slowly pull retainer assembly off motor housing and external pump.

Follow steps removing the internal auxiliary pump and seal per section 10.

Replace retaining ring (8) figure 4.

Remove shaft seal. Follow seal assembly in reverse order.

See seal assembly per instructions below.

After seal is replaced re-install retaining ring (8) figure 4 and reassemble auxiliary pump and unit per assembly instructions.

CAUTION Failure to follow these instructions may result in pump failure.

SEAL ASSEMBLY

Procedure for Installation of Mechanical Seal Seals

Use only clean hydraulic fluid from the test cylinder system to lube into the seal. The fluid must be compatible with the type of seals being installed. Ensure that both ends are clean at all times when handling seals.

Install the shaft into the unit per procedure.

Assume that the seal faces of the support and mounting rings remain clean throughout the installation. These parts have highly polished finishes which must be maintained to seat properly.

Lubricate the seal ring on the outside of the seal stator (bottom) when installing the seal retainer. Inspect the back of the retainer to assure that the seal ring and stator are seated completely and squarely into the retainer and the stator is not tipped. Care must be taken to assure that the stator is not damaged. Avoid any impact on this piece.

Install carbon rings into grooves on the seal retainer as required.

Lubricate the shaft in the seal stator, the ID of the shaft bearing, the face of the shaft and the face of the carbon ring. Without touching the face of the carbon seal, slip the assembled spring and rubber boot onto the shaft until the spring remains bottomed. Align the seal retainer and mounting flange bolt holes and position the assembly down with the seal stator face against the carbon faces, pull the seal retainer in the mounting flange pilot taking care to keep the part as even as possible. Tighten (Do not use impact tool) with 4 screws and torque to 100% of regular specification.

Allow the unit to sit for a minimum of one hour before running to allow time for the seal to bond to a secure fit in the shaft.




FIGURE 7

'B' mounting position shown

PARTS LIST FOR FIGURE 1

Item	Description	part no	quantity
1	No. 2 plunger shaft assembly	322-12474	1
2	see figure 1		
3	No. 2 fixed seat assy	322-12476	1
4	see figure 1		
5	seat retainer	039-87472	1
6	seat seal	829-00015	1
7	seat retainer O-ring	071-00246	1
8	hex. head screw	306-40123	1
9	not used		
10	not used		
11	not used		
12	balance plate	032-70546	2
13	spacers	032-31247	2
14	302-160 cap screw	259-02180	2
15	M10x1.0 washel	031-43007	8
16	hex. head washer screw	359-25018	18
17	control assy. input	see below	1
18	control assy. input	see below	1
19	Not used		
20	Not used		
21	Screws	032-91056	1

OPTIONAL CONTROLS

See page 64. Also see catalog ST-ZAM-7501-A.

COUNTERBALANCE PLATE ASSEMBLY

See figure 1. Place the two spacers (13) on the screws (11) and install (10) the balance plate (19).


Tighten with the crosshead nuts on balance stem and tighten. Torque to π 16-18 N.m (1.6-1.8 ft-lb).

SERVO PLATE ASSEMBLY

Replace servo plate (1) if was removed. If used previously repeat steps 10 to 15. Insert screws (18) on bores.

CONTROL COVER ASSEMBLY

PORT BLOCK ASSEMBLY



Install the cover assemblies (14 & 15) over the cover pins on the housing pins and secure with lock (12) and sleeve (13). Torque to 20 lbf-ft, 45 Nm.

See figure 8. Position the port block (1) on a clean flat surface with two open ports up. The listed items which can be scratched or damaged:

• Compress the ring check (2) and install in the two system port and drain holes in the (3) with the side slot in the port hole.

• Place lockwashers (5) on stems (4) and install screws through port/well/bushing/steck and thread locknut (3). Torque to 20 lbf-ft, 45 Nm.

• Install two check valve assemblies (11) in valve face of port block. Torque to 20 lbf-ft, 45 Nm.

• Install three hex soc. plugs (8) (check rings (10)) into port block. Torque to 18 lbf-ft, 25 Nm.

• Install hex soc. plug (12) and C-ring (11) into port block. Torque to 30 lbf-ft, 50 Nm.

• Install AVSEAD® plugs (3) into port block.

PARTS LIST FOR FIGURE 8

Item	Description	Part No.	(P24-30P) S23-15105 Quantity	(P24-30S) S23-15127 Quantity
1	port block	003-91564	1	—
2	port block w/ shuttle (3)	003-91564	—	1
3	ring check	038-72359	2	2
4	hex soc. pin/screw	359-11142	2	2
5	lockwasher	442-10018	2	2
6	ring bushing	038-72398	2	2
7	shack valve assembly	213-42266	2	2
8	C-ring	081-00906	8	8
9	hex soc. plug	388-35044	13	13
10	hex soc. plug	388-35048	3	3
11	o-ring	081-00908	3	3

PORT BLOCK INSTALLATION

See figure 9. Position the pump with open end of the bearing assembly (18) facing the metal flange gasket (15) on the housing. Do not use gasket position.

Install two bolt plate pins (17) to the face of the port block assembly (2) and the cover pins (1) into mounting surface of port block.

Insert lifting eyes into stepped holes in each system port mounting surface.

Apply heavy grease to the rest of the bolt plate (17) and install over the bolt plate pins.

Temporarily attach port plate to port block by inserting a bolt through one of the 2" (50.8 mm) diameter holes down through the port block bolt through gasket in the port plate, around web back through port block and the ends of the bolt to lifting eye. Repeat this step to the other side of the port plate.

Install the port block assembly over the auxiliary shaft and section onto tubes and cover pins while engaging discharge-feed tubes.


CAUTION: Use extreme care and slowly lower the port block carefully into the four tubes which are precision fit to the port block. Check when the block is within 1/2" (12.7 mm) of seating that the tubes are squarely in the holes and the bolt plate is seated firmly against the block. Lower the pump until the joint is seated.

Install the six bolt and washers (11) & (9) (6, 11 & 16). Do not drop the bolts in place as the threads will be damaged. Torque bolts evenly. Torque coils (11) in sequence: 67.5 Nm increments to 450 lbf-ft, 510 Nm and the two nuts (9) to 120 lbf-ft, 160 Nm righten left turn all six bolts. Counter-tighten two bolts (fig 6) items to 120 lbf-ft, 160 Nm.

CAUTION: Do not use tools that may damage to the flange mounting surface while installing and torquing the bolt bolts.

PARTS LIST FOR FIGURE 9

item	description	part no.	quantity
1	hex. hd cap screw pwdr.	806-40021	4
2	hex. hd cap screw beng.	906-40020	4
3	bolt block assy.	322-15105	1
4	bolt block assy. w/chock 181	322-15127	1
5	bolt plate dm	324-24610	2
6	H.H. bolt plate 24	033-71732	1
7	H.H. port plate 30	033-91238	1
8	L.H. port plate 24	033-71733	1
9	L.H. port plate 30	033-91237	1
10	bolt block gearer	033-91086	2
11	housing assembly 24	322-12586	1
12	housing assembly 30	322-12178	1
13	lower pin	324-24832	2
14	hex. hd cap screw	806-40022	3
15	washer lock slt	360-10136	2
16	washer lock slt	360-10135	4



**BARREL HOLDDOWN
24 SERIES**

See figure 9 & 10. Use special tool T2 and turn over auxiliary shaft and engage the holes in the hold-down adjusting screw (6), figure 4. Carefully tighten until screw bottoms out.

NOTE: The main drive shaft must be held to prevent barrel assembly from turning. If barrel assembly turns, measurement cannot be made.

Remove special tool T2 and sight through hold-down screw and note where both of auxiliary shaft spline is located.

Back off hold-down screw loose to 10 clockwise teeth on auxiliary shaft approx. 186°.

NOTE: Turned hole in hold-down screw must line up with spline between spline teeth. Barrel lift-off is now set at 0.077" (3.6 - 5.81 mm).

Use a large edgew driver with the sides of the blade ground down so it passes along side the box and can clear the screw slot. Thread hold-down adjusting screw (6), figure 4 into hold-down adjusting screw. Torque to 30 ft-lb, 40.7 Nm.

Turn hold-down lock (bearing ring) (1) figure 4 over auxiliary shaft into groove which is located 5.92 - 14.05 mm from end of shaft.

ASSEMBLY PROCEDURE

See figure 4, 5 & 10. Use special tool TC-1000 to move auxiliary shaft and engage gear side into lockdown cover assembly (5). Figure 4. Carefully tighten lockdown bolt until the lockdown screw assembly bottoms out.

NOTE: The main drive shaft must be held to prevent barrel assembly from turning. If barrel assembly turns the adjustment cannot be made.


Turn off lockdown screw assembly 140° counter-clockwise.

Barrel lift-off is now set at 0.025" (0.81mm).

Remove socket wrench. Rotate drive shaft to check if any binding occurs.

Lock lockdown screw assembly (1) by tightening the six socket head cap screws gradually in the following torque sequence until 65 lb-in (7.4 Nm) torque is reached.

NOTE: If barrel lockdown has to be re-set for any reason all six socket head cap screws must be loosened gradually in the same order they were tightened. Do not remove screws completely. Use the #10-32 UNF threaded hole in the front face of the gear limit from lockdown cover assembly (5) to assist in locking barrel lockdown.



Torque sequence for locking lockdown screw assembly.

AUXILIARY PUMP

See figure 10. Slip sealing washer (1) into bore in port block, over auxiliary shaft and seat (4) in housing (2).

With auxiliary block face of the port block located at 12 o'clock position, the sleeve pin hole for valve cartridge assembly (2) in the port block is located between 1 o'clock and 2 o'clock positions.

Grease sleeve pin hole with grease.

Insert valve cartridge assembly into port block, maintaining sleeve pin hole (2) in valve cartridge assembly (2) against sealing washer (1).

NOTE: Thread front end of valve cartridge assembly to base of port block 62.5° over 20.6 ± 0.05 mm.

With valve cartridge seated, remove sleeve pin.

END COVER

Apply a light film of oiling grease to O-rings (3), (4) and (5) and place O-rings (3) and (4) around pilot of end cover (6). Place tetraseal (5) in groove in face of end cover.

Apply a light film of oil or grease to O-ring (11), and place on plug (10). Thread plug into end cover and tighten.

Engage pilot of end cover into port block. Refer to figure 10 for G port positioning. Align hole and secure with screws (17). Torque to 3.00 lb-in (37.42 Nm).

Apply a light film of oil or grease to O-ring (8), and place on plug (9). Thread plug into end cover and tighten.

Apply a light film of oil or grease to O-ring (21), and place on plug (20). Thread plug into port block.




FIGURE 11

PARTS LIST FOR FIGURE 10

item	description	part no	q'ty
1.	sealing washer	033-91073	1
2.	cartridge assembly CW 231 mm rev. 46.1 outer	S24-11418	1
3.	cartridge assembly CW 231 mm rev. 46.1 outer	S24-05562	1
4.	cartridge assembly CW 134 mm rev. 26.9 outer	S24-11789	1
5.	cartridge assembly CW 134 mm rev. 26.9 outer	S24-51296	1
6.	cartridge assembly CW 135 mm rev. 17.2 outer	S24-11697	1
7.	cartridge assembly CW 135 mm rev. 17.2 outer	S24-11778	1
8.	cartridge assembly CW 3.56 mm rev. 88.1 outer	S24-05342	1
9.	cartridge assembly CW 3.56 mm rev. 88.1 outer	S24-05638	1
10.	cartridge assembly CW 4.84 mm rev. 79.3 outer	S24-05608	1
11.	cartridge assembly CW 4.84 mm rev. 79.3 outer	S24-05610	1
12.	cartridge assembly CW 5.42 mm rev. 68.8 outer	S24-05562-0	1
13.	cartridge assembly CW 5.42 mm rev. 68.8 outer	S24-11844-0	1
14.	cartridge assembly CW 6.10 mm rev. 100.0 outer	S24-05533-0	1
15.	cartridge assembly CW 6.10 mm rev. 100.0 outer	S24-05534-0	1
16.	cartridge assembly blank	S24-15102	1
2a.	o-ring	891-00238	4
2b.	labyrinth	891-10229	4
3.	o-ring	871-00238	4
4.	o-ring	871-00242	1
5.	labyrinth	891-10028	2
6.	end cover std	033-91583	1
7.	endcover W/SAE-107-3 (B)	033-91508	1
8.	endcover W/SAE-127-3 (Q)	033-91524	1
9.	arrow, std. br. cap	388-28247	8
10.	o-ring, std.	891-00232	1
11.	o-ring, std.	488-25050	1
12.	o-ring, std.	488-25024	1
13.	o-ring, std.	891-00816	1
12.	hex. Rd cap screw	806-40128	6
13.	said SAE-B only	821-83065	1
14.	bolt/blind SAE-22-4 (B spline)	033-57214	1
15.	coupling SAE-32-4 (C spline)	033-57316	1
16.	retreasel (P24-308)	891-10214	2
17.	o-ring (P24-308)	871-00223	1
18.	nut/center (P24-308)	033-91185	1

PARTS LIST FOR FIGURE 10 (continued)

Item	Description	Part No	Qty
18	screw 1/2-12 x 2 1/2	680-002803	4
19	shuttle valve assembly	929-1988	1
20	plugs, oil filter	488-35041	2
21	o-ring	691-000008	2
22	o-ring SAE-B	671-00455	1
	o-ring SAE-C	671-00458	1

gear drive adapter

See figure 10: A special tool T4 (refer assembly tools) is required to press shaft seal (13) into SAE-B adapter. Place spacer on a clean surface with protruding lip. Use tool to drive seal into adapter. While seating, first the white lip of seal is immersed side is toward inside of the adapter.

Apply a light film of grease on o-ring (21), install in plug (20) with thread into cartridge port and tighten.

Apply a light film of grease to sealing groove on adapter sealing face (12) of port block face. Place labyrinth (15) in groove in adapter and o-Ring (11) in groove in port block face.

Apply a light film of oil of grease on o-ring (13); and place around pilot dia. of adapter. Engage pilot or adapter into bore of port block. Align nosecap and secure with screws (11). Torque to 45 lb-ft (58.4 Nm).

Install coupling (14) into valve cartridge (2) and into auxiliary drive shaft (2) (fig. 9 or 11).

pilot valve assembly

See figure 11: Insert seal (12-6) into cup (29) and seat it bottom of bore.

Insert small end of piston (2-9) into o-ring (2-11), install shaft-end piston or block (2-7) into bore with pilot seal.

Install spacer (2-3) and secure in place with set screw (2-8).

Install spring (2-11) onto case (2-8), install spring (2-10) over o-ring (2-11).

Install O-ring (2-14) to piston (2-12), install small end piston, install into cup (2-3) and seal (2-8).

Install plug (2-15), screw (2-17) and nut (2-16). See (a) requirement and (b) with screw (10) (fig. 12-10).

Install plug (2-9) into bleed air fitting (2-10).

Insert orifice plug (2-1) in center hole in cap, grease and install O-rings (2-2).

shuttle valve assembly

See figure 11: Cage spool (3) and insert impulsive body (1). When the spool is fully engaged, make the spool body turn left a few times (counter clockwise open/close). Spool must move freely in body bore.

Install spring stop (4) into end of valve body (1). Make sure it is seated properly.

Install spring (5) into valve body (1) over the spool (3), install plug (12) and O-ring (15) into the valve body (1). Repeat (b) on the other end of valve body.

Push O-ring (15) and place over the sleeve (6) and install into bore of valve body (1). Be careful not to hit sleeve in bore.

Insert plug (6) into sleeve (6) and place spring (7) into plug (6).

Lube O-ring (10) and place bolt to the sleeve (6).

Line O-rings with bolt come in pilot valve sub-assembly (2).

Mount pilot valve sub-assembly (2) onto shuttle block (1). Use three sets of lock washers (14) and one drilled head screw (13) to secure with the pilot valve sub-assembly. Make sure that the screw that comes with the valve cap sub-assembly is positioned on end closest to acorn nut. Torque to 60 lb-ft (80 Nm). Run lead wire whilst coming with valve cap sub-assembly through hole in special screw and connect Nut. Twist leads together.




FIGURE 11 EXPLODED VIEW OF SHUTTLE VALVE
 EXPLODED VIEW OF PILOT VALVE EXT. DRAIN

PARTS LIST FOR FIGURE 11, S23-11B66

Item	Description	Part No.	Quantity
1	shuttle block	032-S2752	1
2	blow valve ext ext drain	S36-22863	1
3	spool	033-07187	1
4	spring spool washer	038-07162	2
5	abutte	038-09549	1
6	piston	036-32902	1
7	spring	035-27547	1
8	spring	035-67181	2
9	O-ring	691-00126	2
10	O-ring	691-00026	1
11	female seal	691-10221	1
12	film	488-36624	2
13	screw hex head cap 1/2-13 x 3-1/2	806-40224	4
14	screw doc doc cap 3/8-24 x 1-3/4	389-16220	8
15	O-ring	691-00915	2
16	plain	488-25014	1
17	O-ring	691-00812	1

PARTS LIST FOR FIGURE 11, S23-11B66 ITEM 2

2-1	O-rings	695-25528	1
2-2	O-rings	695-00013	4
2-3	film	038-09543	1
2-4	seal b/r/m	312-25061	1
2-5	ozone	036-27583	1
2-6	piston	036-11584	1
2-7	block	036-11213	1
2-8	seal	036-11092	1
2-9	piston	036-12208	1
2-10	spring	038-26496	1
2-11	rim	038-85514	4
2-12	screw doc lid cap 3/8-24 x 1-3/4 w / wash face	036-36748	1
2-13	piston	036-21787	1
2-14	O-ring	675-00012	3
2-15	film	038-21785	1
2-16	hex nut 5/16-24	333-(300)	1
2-17	screw square set 5/16-24 x 1-5/8	312-18309	1
2-18	ozone	036-29474	1
2-19	hex socket allen	431-90104	1

See figure 10. Lubricate piston (15) mating faces and place in the bore in shuttle valve assembly's (17) mounting surface.

Carefully attach shuttle assembly to body block using two lock cap screws (18). Torque to 7.5 lbs-ft, 10.2 Nm.

Note: Ball valves (6) cannot extend in non-symmetrical direction and can be mounted only one way.

See figure 11. Lubricate piston (11) mating faces in bores of shuttle valve's mounting surfaces.

Carefully attach shuttle valve to shuttle valve adapter using screws (13). Torque to 7.5 lbs-ft, 10.2 Nm.

Note: Ball valves (6) cannot extend in non-symmetrical direction and can be mounted only one way.

SHUTTLE VALVE MOUNTING

VALVE BLOCK ASSEMBLY

Figure 12.

NOTE: Prior to assembly of reconditioned parts, check finish of gasket surface on valve block and receiver. Must have 60 rms finish with no grinding marks when tight assembly occurs. If tapping is necessary, check depth of pockets to valve seats after tapping. Must be 0.85 - 2.16 mm minimum after tapping to provide clearance for valve seats.

NOTE: Do not use impact tools to screw tighten threaded parts.

Wash, dry and oil parts. During assembly, keep cast and ground surfaces should be kept lubricated with clean oil and protected from nicks or surface damage.

Place valve body (1) with the six poppet holes facing up in order to press two relief pins (23) in position. Pin pitch is 12.404 mm below surface of valve block. Not indicated after 3-28.

Install four outlet rings (11) into valve block (1) and tighten in place.

This can be the main assembly (1-4) and can continue with the following steps.

Install the orifice screw of the strainer assembly into valve block. Thread screw stop nut onto the orifice screw and torque to 2.25 lbs-in., 2.5 Nm.

Install main filter screen on central support arm sleeve. If placed with socket head cap screw 6-32 X 1/4" lg. Torque #6-32 screw to 13 lbs-in., 1.47 Nm.

Place valve block with poppet valve ports facing up. Position gasket (28) on valve block. Lubricate gasket with oil, hydraulic fluid.

Place springs (33), 1.43" 36.32 kg, into bores at each end of the valve block. Place sequence poppet (30) over these springs. Position seats (27) small shoulder side first over poppet.

Place spring (35), 1.08" 27.66 mm, lg. into bore next to the sequence poppet valves of two steps previous. Place dual relief poppet (31) over these springs. Position seats (29) with the groove side facing up over poppet.

Place spring (32) into bore next to compensation valve side of block. Install replacement bobbin over bobbin. Position seat (28) with the groove side facing down over bobbin.

Insert spring (35) into the remaining hole. Place spring number (34) in spring. Place servo poppet (31) over the retainer and spring. Position seal (28) with the groove side facing down over bobbin.

Carefully position the retainer plate over seats and poppers. Pressing with one hand on the valve component, bobbin and poppet far enough to accommodate three two button lead cap screws (49) in far enough to hold the retainer plate. Install the other two screws and alternately tighten screws. Torque to 9.6 lbs-in., 1.33 Nm.

Lubricate o-ring (4) and install in to seal (8), then install in valve body. Be careful not to damage bore in the seat. Torque to 1.5 lbs-in., 0.24 Nm.

Apply grease to shaft of cone (13) and install spring (12) on cone. Carefully insert cone and spring into valve block positioning point of cone into bore of seat.

Lubricate o-Ring (11) install in groove of piston (10) and insert end of piston into spring (12).

Lubricate o-ring (9) and install in bearing guide (8) into thread into valve block. Tighten in place.

Thread nut (7) on socket cap screw (6) with lock washer (5) and lock nut (4) until it comes to compression spring.

ASSEMBLY PROCEDURE

(continued)

Using a small headed screw driver, thread the push retarding relief valve assembly (26) into valve block and lightly tighten. If necessary, do not over-tighten, as cause sides of bolt to break, making next removal.

Lubricate o-ring (4) and install on plug (25) and spin-on plug in place.

Thread check valve (22) into valve block and lightly tighten in place. Do not over-tighten. Lubricate o-ring (23) and installation plug (23) and tighten in place. Repeat step on other end of valve block.

Lubricate o-ring (18) and install on plug (25) and tighten in place.

Install pin (24), Lubricate o-ring (22) and install base plug (23) and tighten plug in place.

Lubricate o-ring (4) and install on plug (25) and tighten in place.

Lubricate Mo-ring (22) and install over two plugs (25) and tighten in place.

Using a small hammer carefully tap roll pins (48) into and thru the retainer plate (42). The pins should bottom out in hole leaving enough length extending out for pinning into the part block.

Lubricate o-Ring (47) (48) and (49) and install in the bottom of retainer plate (42).

WAVE is ready to install on pump.


PARTS LIST FOR FIGURE 12

item	description	part no	quantity
1.	valve block P24P/S	033-91221	1
2.	valve block P24P/S w/ P-2400 w/ SA control	033-91221	1
3.	check valve assembly	S13-40066	3
4.	orange plug	033-91249	1
5.	o-ring	891-00005	1
6.	seal	032-71006	1
7.	screwscrew 6/18-24 x 11/16	312-13160	1
8.	hex. nut nut 6/18-24	833-13100	1
9.	handling cap	033-73346	1
10.	o-ring	891-00910	1
11.	seat piston	033-21197	1
12.	o-ring	891-00012	1
13.	galling	02-91798	1
14.	o-ring	032-12200	1
15.	servo actuator assembly	S13-43240	1
16.	o-ring	891-00906	1
17.	plugs	488-26502	1
21.	roll pin 1/8 x 3/4" L P24P/S	322-20810	1
22.	roll pin 1/8 x 3/4" L P24P/S & P24/30P w/ SA control	233-82170	1
23.	o-ring	891-00904	3
28.	plug	488-26501	3
26.	plug	488-26503	2
29.	roll pin	322-12120	4
27.	septum seal	032-71507	2
30.	repaintable service port	032-71001	1
29.	valve block gasket	033-91190	1
30.	sequence poppet	033-72378	4
31.	anti-surge poppet	033-22379	4
32.	repaint seating	033-22141	1
33.	sequence & servo seating	033-72512	3
34.	spring retainer	032-71392	1
35.	stainless steel	032-71188	1
36.	boot tapered valve	S23-12890	1
	boot tapered valve P24/30P	S23-12813	
	boot tapered valve P24/30P w/ SA control	S23-12814	
37.	o-ring	891-00003	1
42.	retainer plate	033-91422	1
43.	button head screw #10-24 x 3/4" L	333-28078	4
45.	lock nut 6/18-24	922-25505	1
46.	roll pin 1/8 x 3/4" L	322-08120	2
47.	o-ring	891-00019	2
48.	o-ring	891-00014	2

Note: assembled after 8-96

STRAINER

(continued)



Assembly No S23-12742 P24P
S23-12794 P30P
S23-127T0 P24B
S23-12795 P30S
S23-12796 P24/30P w/9A control

FIGURE 12:

Figure 10

NOTE: Prior to assembly of reconditioned parts, check finish of gasket surface on valve block and retainer. Must have 60 rms finish with no grinding marks which might carry oil to outside surface. If lapping is necessary, check depth of pockets for valve seats after lapping. Must be .085" .216 mm minimum after lapping to provide clearance for valve seats.

NOTE: Do not use impact tools or over tighten threaded parts.

Wash and dry all parts. During assembly, lapped and ground surfaces should be kept immersed with clean water and protected from rust and surface damage.

Place valve block (1) with the six poppet valves bowed up in order to press two collars (.261" diameter) off pins in at 1/2" 3.04 mm below surface of valve block. (Refer to figure R-26).

Install four collars, plug (9), into valve block (1) and tighten in place.

Disassemble the stellite assembly (114) and reassemble per the following steps:

Install the outer cover of the timing assembly into the block. Thread the top nut onto the outer screw and torque to 23 lbs-in. / 2.6 Nm.

Install main roller street on timing support and secure in place with lockset lock cap screw 6-32 X 1/4" lg. Torque #6-32 screw to 13 lbs-in. / 1.47 Nm.

Place in the slots with poppet valve bases facing up. Position retainer (29) in valve block.

Place spring (28) "A2" 26.22 mm lg. into each mold base slot in each end of the valve block. Place sequence poppet (30) over these springs. Position seats 1271 small diameter side first over poppet.

Place springs (35) 1.08" 27.88 mm lg. into holes next to the sequence poppet valves of two-step pressure. Place dual relief poppet (31) over these springs. Position seats (29) with the groove side facing up, over poppet.

Place spring (32) 1.6" 38.0 mm lg. into bore next to compensator valve side on block. Install relief/rif poppet over spring. Position seat (29) with the groove side facing down over poppet.

Insert spring (33) 4.43" 38.3 mm lg. into retainer seating bore. Place zero poppet (34) over the retainer and spring. Position seat (44) with the tapered bore facing down over poppet.

Carefully position the retainer plate over seats and poppets. Pressing with bone (1) and on the valve block, compress seats, poppers and springs so enough to alternately thread two flange head screws (43) in the enough to hold the retainer plate. Retighten the other two screws and alternately tighten screws. Torque to 80 lbs-in. / 3.39 Nm.

Install o-ring (4) and installation screw (6). Thread into valve block. Be careful not to damage bore in the seat. Torque to 15 lbs-in. / 2.04 Nm.

Apply machine脂to shank of cone (13) and install spring (12) to cone. Carefully insert cone and seating into valve block positioned point of cone into bore of seat.

Install o-ring (11) seated in groove of cone (13) and install end of cone into spring (12).

Install o-ring (9) and installation O-ring guide (8) into threaded hole in valve block. Tighten in place.

Thread nut (7) on pocket set screw (6) and thread cone into housing (8) until it starts to compress spring.

Using a small headed screw driver thread the pool retainer ring retainer assembly (36) into valve block and lightly tighten in place. Do not over tighten. Over tightened can cause seal to break now that next removed.

Lubricate o-ring (4) and install on plug (25) and tighten plug in place.

Thread sheet metal (22) into valve block and lightly tighten in place. Do not over tighten. Lubricate o-ring (22) and install on plug (23) and tighten in place. Repeat step on other end of valve block.

ASSEMBLY PROCEDURE

Figure 13
(continued)

- Lubricate O-ring (19) and install o-ring (20) and tighten plug in place.
- Lubricate O-rings (22) and install oil plug (23) and tighten plug in place.
- Lubricate O-ring (3) and install oil plug (25) and tighten plug in place.
- Lubricate O-ring (19) install rm plug (2) and tighten plug in place.
- Lubricate O-rings (47) and install in underside of manifold block (15). Carefully, place manifold block (16) on top of the valve cover (1) making sure the O-rings are correctly seated. Secure with four socket head cap screws (41) to the block (15).
- Insert spring (16) and spacer (48) into manifold (15) with the spring going into spring housing (the left side of the manifold (15) when viewing from the top). Install oil line plug (61) to manifold (15).
- Install temporary plug (30) in 1/4" 8.35 mm tube port. Insert O-ring (19) and plug (29) in alternate drain port.
- Using a small hammer carefully tap retainer pins (48) into retaining plate (42); the pins should bottom out in hole leaving enough length sticking out for plotting into part block.
- Lubricate O-ring (47), (48) and (37) and install in the bottom of retaining plate (42).

Valve assembly complete.


figure 13
(continued)

PARTS LIST FOR FIGURE 13.

item	description	part no	quantity
1	servo-rod	033-91996	1
2	check valve assembly	S13-40268	3
3	o-ring	033-91249	4
4	bushing	891-00902	2
5	seal	033-70508	1
6	300 id screw 8-15-24 x 1" lg	312-19180	1
7	hex nut m3 18-4	891-11100	1
8	bushing guide	032-70549	1
9	o-ring	891-00810	1
10	seat plate	036-21781	1
11	o-ring	891-00012	1
12	spring	036-91798	1
13	bolts	036-12288	1
14	servo cylinder assembly	S13-93240	1
15	membrane	033-64893	3
	membrane: servovalve-line W7F or TG control	033-64446	
16	spool	033-93283	1
17	o-ring	891-00906	1
18	plugs	488-36041	2
19	o-ring	891-00904	1
20	plugs	888-35001	1
21	spool servovalve-line w/ r. m. 16 control	033-54489	
22	plugs	198-21683	2
23	roll pin	325-12120	2
24	sequence seat	033-71360	1
25	replenish a servo seat	033-71360	1
26	servo relief poppet	033-71361	1
27	sequence poppet	033-72378	1
28	partial replenish poppet	033-72379	1
29	replenish spring	033-22111	1
30	sequence & control spring	033-70512	1
31	servo relief poppet	033-64608	1
32	replenish relief spring	033-71086	1
33	filler relief valve	322-12899	1
34	o-ring	871-00060	1
35	screws	033-54992	1
36	o-ring	891-00306	1
37	300 id screw #10-24 x 1-1/4" lg	312-19183	4
38	retainer plates	033-91422	1
39	screws	368-26073	3
40	servo relief seat	033-54389	1
41	stamp out 5/16-24	027-92006	1
42	roll pin 1/8 x 3/4" lg	325-08120	2
43	o-ring	871-00013	1
44	plugs	871-00014	2
45	plugs 7/16-19	449-00013	1
46	300 id screw 3/8-16 x 4" lg	368-16300	4
47	plugs	033-90332	3
48	filler reservoirs w/ r. m. 16 control	033-51085	2
49	filler reservoirs-line W7F or TG control	891-00011	2
50	pin servovalve-line W7F or TG control	323-02208	1
51	hex id screw 4-40	804-40732	1
52	sollte #33 1/4x2" 1.18mm	033-08526	1

*Not required after q-86

Figure 13
(continued)



Assembly No. S23-12776 P24P/P30P & P24S/P30S

Assembly No. S23-12798 P24P/P30P & P24S/P30S
w/ servo valve adapter & cutoff compensator control

FIGURE 13

TEST PROCEDURE

Maximum output between pump shaft and system max. temp. 60°C (140°F, min. 10°C)
 indicates cooling.

Electric motor speed: 1800 rpm.

Inlet temperature = 120°-140°F 500-580C

Net condition: 24 series 193 rpm min. 10.3 bar/min.
 30 series 225 rpm min. 16.5 bar/min.

Internal valve pressure 101 kPa = 5 psi 254 mm Hg to 34 bar (except V series)

Case pressure 65-75 psi 3.81-5.19 bar

Fluid = 200 SAE oil at 100°F, 46 SAE at 40°C

BASIC PUMP TEST

Mount pump and test stand. Connect system lines and interface (external) with auxiliary drive. Turn pump inlet torque. Fill pump case with clean oil. Draw oil from pump to prevent trapping air external tanks.

Start electric motor. Log several times before continuous running.

Rotate pump input control shaft. The servo control should control pump displacement through its full range. Set pump displacement to full volume and adjust system pressure (> 1000 psi, 69 bar). Check and record system flow and temperature with pump above and below center. Monitor loop temperature.

Minimum system flow: 24 series 194 gpm, 734 Lpm
 30 series 241 gpm, 912 Lpm

Minimum case drain flow: 24 series 4.6 gpm, 17 Lpm
 30 series 5.8 gpm, 21 Lpm

Set oil compensation dial to zero with full compensated output. Turn off pump. Observe volume indicator and stroke rotary servo input shaft from full to full position on each side of center. Record stroke from oil cavity near zero position to oil compensation dial from oil cavity until return commences, adjusting dial to its original position and proceed with next step.

Caution: Do not over tighten cap screw.

Cycle pump at 10 second intervals full volume above center to full volume below center as follows:

- 10 minutes at 1000 psi, 69 bar
- 10 minutes at 550 psi, 37.2 bar
- 10 minutes at 500 psi, 34.5 bar

*Pumps with system adjustment controls do not need to be cycled.

Adjust system pressure to 5000 psi, 345 bar and set pump displacement to full volume. Check and record system flow and case drain flow above and below center.

Minimum system flow: 24 series 160 gpm, 608 Lpm
 30 series 220 gpm, 865 Lpm

Minimum case drain flow: 24 series 12 gpm, 45.4 Lpm
 30 series 18 gpm, 68.4 Lpm

Set pump to compensate at 6000 psi, 414 bar. Servo pressure should be at least 600 psi, 41.4 bar. Check and record internal valve pump flow.

Model: IP**P-xxxx-xxx-x-xx-xx

Valve pump case	0	1	2	3	4	5	6
case rev	231	151	105	3.85	4.81	5.42	6.11
psi/bar	16.1	26.4	17.2	38.8	79.3	88.8	100.0

Min. flow at 1850 rpm	0	1	2	3	4	5	6
Lpm	313	118	74	32.4	27.0	34.5	48.8
gpm	80.8	48.7	20.0	102.2	140	157.1	177.3

TEST PROCEDURE

Set pump to compensate at minimum pressure, check valve reseating and set to pressures:

Servo pressure - minus leakage pressure:

30/24 series: 160 to 220 psi, 11 to 15 bar

*Replenish pressure + minus valve pressure:

Std - 30/24 series: 180 to 220 psi, 12.4 to 15.2 bar;

3" version: 220 to 370 psi, 15.5 to 25 bar

If pressures are incorrect, remove replenishing relief valve, plot load increase or decrease measurements required. One full turn on adjusting screw will cause pressure to change approximately 25 psi (1.7 bar). Re-torque locknut to 21-26 lbs-in, 2.3-2.8 Nm.

*Replenish pressure may be set to customer requirement, not to exceed 450 psi (31 bar).

NOTE: There is no servo relief valve adjustment, increasing or decreasing replenishing pressure will cause both servo and replenishing pressure to change by the same amount.

Set the pump to compensate at 3000 psi, 345 bar, record replenishing and servo pressures:

Servo pressure - minus replenish pressure:

24 series: 280 to 420 psi, 19.6 to 29 bar

30 series: 472 to 532 psi, 32.5 to 37 bar

*Replenish pressure - minus valve pressure:

Std - 24 series: 180 to 220 psi, 12.4 to 15.2 bar

30 series: 200 to 240 psi, 14 to 17 bar

3" version: 230 to 370 psi, 15.5 to 25 bar

Set pump to compensate at minimum pressure. Set maximum load to 104% of the previous step.

NOTE: After completing last step, proceed with pump control test. **Refer to control service manual S1-AM030.** Continue with the next steps after control testing.

Lower pump displacement for full volume and adjust system pressure to 3000 psi, 345 bar. *Adjust compensation from 5000 psi, 345 bar, minimum system pressure at 1000 psi, 69 bar intervals. At each pressure, stroke rotary servo input shaft to the full position (no visible of center). Cam indicator should remain close to very near the zero position with no oscillation. System pressure should not vary from port "A" to port "B" more than 150 psi (10.3 bar) and no oscillate.

CAUTION: Do not hold pump at 5000 psi, 345 bar for longer than one minute, doing this is likely an intermittent pressure setting.

Minimum compensation pressure should be 1000 psi (69 bar).

Increase compensation adjustment to 1000 psi, 70 bar and increase and decrease system pressure above and below compensation setting. When system pressure is above compensation setting, the pump should be stroke and not oscillate, when the system pressure is below the compensation setting the pump should stroke a full volume. Repeat at 5000 psi, 345 bar.

Check pump for external leak. No external leak(s) detected.

After all tests are completed re-torque main housing bolts to 380 lbs-ft, 476 Nm.

ALTERNATE TEST PROCEDURE

GENERAL REQUIREMENTS

The following test procedure may be used if the standardized equipment is not available.

Maximum (allow between) pump shaft and seal/coupling shaft 0.02 (0.076 mm) total indicator reading.

Electric motor speed = 1800 rpm.

Intake temperature = 120°-140° F, 50°-58° C.

Test conditions = seal pump 24 series 160 psi min 10.9 bar
30 series 220 psi min 15.5 bar

Internal valve ports = 10° 25° mm Hg to 5 bar 0.34 bar

Cage pressure 85-75 psi (2.8-5.2 bar) except S' pump

Fluid = 200 SS4 at 100° F, 45°C at 40°C

TEST PROCEDURE

Mount pump on test stand. Connect system lines and internal case pump inlet to pump. Fill pump case with case oil. Dry start from pump to permit checking external leak.

Start pump motor. Log several times before continuing further.

Rotate pump input control valve. The servo control should control pump displacement 100% up to 100% down. See pump displacement vs. full volume, and displacement pressure up to 1000 psi, 69 bar. Check and record system flow and case drain flow with dam above and below center. Monitor temperature.

Maximum system flow: 24-series 194 gpm, 73.4 Lpm
30-series 241 gpm, 91.2 Lpm

Maximum case drain flow: 24-series 4.8 gpm, 17 Lpm
30-series 5.5 gpm, 21.4 Lpm

Back out compensator adjusting screw until it is fully compensated count clockwise of turn. Observe volume indicator and stroke many servo input cycles, full to full position in clockwise of center. Volume should remain at 0% of rev. Rev counter position. If compensator functions normally, tighten compensator adjusting screw till its original position and proceed with next step.

Caution: Do not over tighten cap screw.

Circle pump at 10 second intervals, fully stroke above center to full volume below center, as follows:

10 minutes at 1000 psi, 69 bar
10 minutes at 2500 psi, 172 bar
10 minutes at 5000 psi, 345 bar

Adjust system pressure to 5000 psi. 24-series initial pump displacement vs. full volume. Check and record system flow and case drain flows above and below center.

*Pump with **internal** bypass (control switch needs to be cycled).

Minimum system flow: 24-series 101 gpm, 60.5 Lpm
30-series 230.69 gpm, 385.4 Lpm

Maximum case drain flow: 24-series 12 gpm, 45.4 Lpm
30-series 12.3 gpm, 49 Lpm

Install special adjusting screw over regulating port or valve tool. Center pump, adjust special adjusting screw to exact 600 psi, 41.4 bar set pressure. Read case drain flow vs. internal valve output flow. See chart. Next basic pump test.

CONTROL TEST

Please refer to control service manual No. S1-AM000 for control information.

item	description
1	piston pump
2	Yoke flange
3	multi servo
4	auxiliary pump
5	servo pressure relief valve (modulated by operating pressure)
6	replaceable pressure relief valve
7	sequence valve
8	compensator valve
9	override pressure relief valve
10	servo pressure sequence valve
11	replaceable check valve
12	external auxiliary boost pump
13	shuttle valve

FLUID CONNECTIONS

specification	term	Gokicup P2430P	Gokicup P2430S
• A-B system SAE code 62 spill flange	mm	20	20
A/G, B/G, A-B system gage straight thread, o-ring seal	SAE	-8	-8
A/G, B/G, A-B system gage straight thread, o-ring seal	SAE	-8	-8
C/G, pump inlet, servo outlet SAE code 61 spill flange	mm	20	20
b1, b2, case drain straight thread, o-ring seal	SAE	-20	-20
b3, shuttle drain	SAE	-18	-18
D/G, case gage straight thread, o-ring seal	SAE	-4	-4
D/G, case fitting for vertical mounted filter, straight thread, o-ring seal	SAE	-4	-4
E/G, external case, pilot valve	SAE	-4	-4
F/A, F/B, control pressure edge straight thread, o-ring seal	SAE	-6	-6
H/C, aux. pump outlet, servo & esp. to external filter	SAE	-12	-12
H/D, aux. pump inlet, servo & esp. from external filter, w/ bid. O-ring seal	SAE	-12	-12
H/E, service gage, straight thread o-ring seal	SAE	-6	-6
K/F, pump replacement filter, inlet straight thread, o-ring seal	SAE	-22	-22
K/A, shuttle relief valve	SAE	-12	-12
M/G, replacement gage, straight thread, o-ring seal	SAE	-4	-4
N/Y, compensator valve, YK, air-escape valve, VB, B-vent, straight thread, o-ring seal	SAE	-4	-4

¹⁾ Reference: viewing from outer end of jumpers port is indicated. Block in the assembly diagram shows which position it is located in the main diagram.




Figure 14
P24/3CP







Figure 15
P24 GOS








NOTES

1. REFERENCED TO HIGH ROTATION (BOW & NODD) MODE
VIEW FROM SIDE OF PUMP
2. EQUIPPED IN PUMP WITH THESE BEARINGS (OPTIONAL)

BASIC MOTOR "B" MODE & V PUMP
WITH 3000 RPM SPEED AND SERVOMOTOR
(OPTIONAL) AND 3000 RPM SERVOMOTOR



23-8819

INSTALLATION DRAWING



A: CONTROL MTG. POSITION							
CONTROL OPTION	PUMP PACKAGE	END PLUGS	PUMP ROT.	SCREW DRIVE IN FRONT BUSH DISCRETE OR FULL	HORN	PORT G	PORT H
*162	P24P	3	CW	CW ROT. FULL TURN	INLET	OUTLET MAX. VOLUME STOP MIN. VOLUME STOP	VOLUME STOP
	P24V	2	CW	CW ROT. FULL TURN	INLET	OUTLET MIN. VOLUME STOP MAX. VOLUME STOP	VOLUME STOP

FIGURE - 2




MANUAL OVERRIDE DETAIL

NOTES:

- FOR PUMPS WITH INTERNAL CARTRIDGE CONTROL
- THIS UNPACKAGED DESIGN IS NOT ROTARY
- P24P BOD INSTALLATION LEC CONTROL 23-9932
- P24V BOD INSTALLATION LEC CONTROL 23-9933
- 23-9932 AND 23-9933 ARE APPROVED BY KHD
- REFER TO CRAFTING
- UNPACKAGED IN TAPERED BORE METRIC (MM)

FIGURE - 1

B: CONTROL MTG. POSITION							
CONTROL OPTION	PUMP PACKAGE	END PLUGS	PUMP ROT.	SCREW DRIVE IN FRONT BUSH DISCRETE OR FULL	HORN	PORT G	PORT H
*162	P24P	1	CW	CW ROT. FULL TURN	INLET	OUTLET MIN. VOLUME STOP MAX. VOLUME STOP	VOLUME STOP
	P24V	1	CW	CW ROT. FULL TURN	INLET	OUTLET MIN. VOLUME STOP MAX. VOLUME STOP	VOLUME STOP







RELIEF VALVE WITH INTERNAL CONTROL
WITH INTERNAL CARTRIDGE
UNPACKAGED DESIGN - 23-9933


23-9933

NOTES

- 1 FOR CHANGES IN THE PORTFOLIO INDUCTION AND HOLDING USE THE APPROPRIATE BACK PAGE OF THE FORM.
- 2 PORTFOLIO INDUCTION (LESS CONTROL) 100,000.00
- 3 PORTFOLIO HOLDINGS 100,000.00
- 4 PERTURBATION PORTFOLIO (PLUS 10% OF THE PORTFOLIO FINANCIAL POSITION)
- 5 DEDUCTIVE INVESTMENT USE THE METRIC (GROSS)






VIEW A-A





A-CONTROL MTG POSITION

A. CONTROLLING POSITION									
INTERVIEW OPTION	PREFERRED ROLE	PREFERRED POSITION	SOCIETAL PREFERENCE		INDIVIDUAL PREFERENCE		PREFERENCE SHIFT ROTATION	PREFERENCE X	PREFERENCE Y
			PERMANENT	TRANSIENT	PERMANENT	TRANSIENT			
PERMANENT	PREFP	PERMANENT	PERMANENT	TRANSIENT	PERMANENT	TRANSIENT	NO	NO	NO
TRANSIENT	PREFP	TRANSIENT	TRANSIENT	PERMANENT	TRANSIENT	PERMANENT	NO	NO	NO
PERMANENT	PREFT	PERMANENT	PERMANENT	TRANSIENT	PERMANENT	TRANSIENT	NO	NO	NO
TRANSIENT	PREFT	TRANSIENT	TRANSIENT	PERMANENT	TRANSIENT	PERMANENT	NO	NO	NO

PRINTED WITH ~~—~~ ON C.R.D.
WITH INTERNAL CARTRIDGE
WATCH ROTATION ISSUE F EDIT 076
23-934 1612



VIEW A-A



12. CONTROL MTS POSITION






B-CONTROLLING POSITION							
POSITION CONTROLLED	FADE-IN	PHASE RATE	CONTACT PRECISENESS	MANUAL DURATIONS	POST %	POST %	
Surf	10%	0.000	MAU-VALUED	MAU-VALUED	0.00%	0.00%	MAUDED
Surf	10%	0.000	MAU-VALUED	MAU-VALUED	0.00%	0.00%	MAUDED
Surf	10%	0.000	MAU-VALUED	MAU-VALUED	0.00%	0.00%	MAUDED

PINPOINT PROBE WITH INTERNAL CARTRIDGE
WITH INTERNAL CARTRIDGE
SWIVEL ROTATION, 5-10 VOLTS INPUT
23-1993-2 of 2

NOTES

FOR FORWARDERS: PERTINENT INFORMATION IS SHOWN
HERE. APPROPRIATE SECURITY POLICIES MUST
BE FOLLOWED. THIS DOCUMENT IS FOR INFORMATIONAL PURPOSES ONLY.
PDR RADIO IS NOT A SECURE COMMUNICATION CHANNEL.
REFERENCE TO FOUR PARTIES THAT HAVE A COMMUNICATED
REVIEWED PRIOR TO RELEASE.

SOME INFORMATION CONTAINED HEREIN IS THE PROPERTY OF LUMITOS





A. CONTRACTING POSITION

A- CONTROL MTG POSITION							
CONTROL OPTION	FOR PICTURE	PROT.	RECEIVED FROM (1) CONTROL UNIT	MANUAL OVERRIDE	MANUAL OVERRIDE MESSAGE ATTACHMENT	PORT IN	PORT OUT
REC	HIGH	ON	OFF	ON	ON	PORTLET	FILE
	MEDIUM	ON	OFF	ON	ON	REPLIER	JUNK
	LOW	ON	OFF	ON	ON	MAIL	ARCHIVE
	OFF	ON	OFF	ON	ON	PORTLET	LOGOUT




PEDAL PAD WITH ONE CORDON
WITH INTERNAL CARTRIDGE
WHEEL ROTATION GEAR & BOLT MTS.
23-0026 | gl 2

NOTE:

- 1) COUPPLING: PROTOTYPING - NO AUTOMOTIVE
- 2) SEE FIG. APPROXIMATE SIGHT PUMP MODEL 3000
- 3) PUMP AND MOTOR ARE BEST MOUNTED IN A VERTICALLY POSITION
- 4) REFER TO PUMP INSTALLATION PLATE IN LUDWIG FRIESE
- 5) USE OF PUMP AND MOTOR ASSEMBLY IS NOT RECOMMENDED
- 6) DIMENSIONS IN PARENTHESES ARE IN MM (INCH)



VIEW A-A



B- CONTROL MTG POSITION

CONTROL OPTION	PUMP POSITION	PUMP RPM	CONTROL PRESSURE TO CONTROL LINE	MANUAL OVERRIDE POSITION	PORT A	PORT B
SAC	Flow	~1000	~100	STAN	INLET	OUTLET
SAC	Flow	~1000	~100	OUTLET	INLET	OUTLET
SAC	Flow	~1000	~100	OUTLET	INLET	OUTLET

PCP CH PUMP WITH SPIN CONTROL
WITH INTERNAL CARTRIDGE
BY WORM ROTATION GEAR FEED WITH
23-0926 2 of 2




FIGURE - 2

A-CONTROL MTG POSITION							
CONTROL OPTION	BUSBAR PACKAGE	HWD REQUIRE	RAMP REQUIRE	STATION SERVICE REQUEST	CHW	CHW	CHW
45	PSR	-	-	CW	CW	WIRE	OUTLET
	PSR	-	-	CW	CW	OUTLET	OUTLET
	PSR	-	-	CW	CW	OUTLET	WIRE
	PSR	-	-	CW	WIRE	OUTLET	WIRE





FIGURE - 1

-B- CONTROL MTG POSITION							
CONTROL COMMAND	REF ID PACKAGE	PUMP SOURCE	PUMP TYPE	RECEIVER SUBSYSTEM	ROTATION	POINT TO PUMP	PUMP TYPE
		I	CW	CW	000	WLL	CCW
	PC48	I	CCW	CW	000	WLL	CCW
	PC50F	I	CCW	CW	000	WLL	CCW
		I	CCW	CCW	000	WLL	CCW

NOTES:
FOR CLASSIFICATION: A PERTINENTLY CORRECT CLASSIFICATION IS THE APPROPRIATE BASIS FOR ALL INFORMATION CONTROLS. PERTINENT INFORMATION CANNOT BE CONTROLLED IF IT IS NOT RELEVANT TO THE DATA. PROXY BIAS IS AN UNDETECTED BIASED PREDICTION.




FIGURE - 2





FIGURE - 1

NOTES:

1. FOR PUMPS WITH EXTERNAL ROTOR. NOT SHOWN. SEE THE APPROPRIATE PUMP INSTALLATION GUIDE FOR APPROPRIATE PUMP INSTALLATION.
2. BASIC INSTALLATION USES CONTROL UNIT PUMP ASSEMBLY. PUMP ASSEMBLY IS TO BE ROTATED 180° IN RELATION TO PUMP ROTATION DIRECTION. SEE NOTE 1.
3. DIFFERENCE TO PUMP ROTATION DIRECTION AT AD. VARIED FROM PUMP SIDE.
4. DATA SHEET FOR PUMP IS SEMI-METRIC (DIN 6885).
5. ELECTRICAL CONNECTIONS ARE TO BE MADE ACCORDING TO THE PUMP MANUFACTURER'S INSTRUCTIONS.

B- CONTROL MTG. POSITION						
CONTROL OPTION	PUMP PACKAGE	PUMP MOTOR	PUMP ATT.	ROTARY SLEEVES/PISTON ROTATION	PORT IN	PORT OUT
P&Z	PORT TOP		1	CW	INLET	OUTLET
			2	CW	OUTLET	INLET
			3	CW	OUTLET	INLET

PUMP PUMP WITH EX- CONTROL
WITH INTERNAL CARTRIDGE
SWIVELLED, NOT A SWIVEL - EXCL 400
23-9914




FIGURE - 2






FIGURE - I



-A- CONTROL		MTG. POSITION			
PUMP NAME	PUMP TYPE	PUMP ROT.	ROTARY SENSORS INPUT ATTACHMENT	PORT #	PORT NAME
PS1	PS1	SW	SW	SW1	OUTLET
PS2	PS2	SW	SW	SW2	OUTLET
PS3	PS3	SW	SW	SW3	OUTLET

ВЫСОТА ОБЩАЯ 100
 ШИРИНА 100
 Т�ЧСТЬ 10
 ДИАМЕТР ЦЕНТРАЛЬНОГО
 ОТВЕРСТИЯ 10
 ГЛУХОЙ ПОДШИПНИК
 СТАНДАРТНЫЙ
 МАТЕРИАЛ
 СТАЛЬ
 ЕЛЕКТРОДУБЛЕР




NOTE:
1. FOR DIMENSIONS & PORT IDENTIFICATION, REFER TO CROWN
SEE THE APPROPRIATE BIRD PLATE ILLUSTRATION.
2. USE THE THERMOMETER COUPLED WITH A THERMOMETER
3. KOBRA BATTERY DISTRIBUTION LINE CONTROL, REFER TO CROWN
RESERVES TO PUMP ROTATION, ROW 1 LIQUID IS AN
HEATED FROM CHILLED.
4. THIS IS THE INERTIAL TUBE METER UNIT
5. EIGHT (8) STAINLESS STEEL 3/8-24 UNI-X
MATING CONNECTORS, PART NO. MC-1016-015-001.

-6- CONTROL MTC. POSITION




-B- CONTROL MTC., POSITION						
CONTROL OPTION	NAME TAG/CHG	PNC FIGURE	PUMP REV.	ROTARY SEWAGE/URI TURBO INLET	PORT REV.	PORT REV.
1	PSH PUSH DOWN	I	CW	CW	INLET	OUTLET
		I	CW	CW	INLET	OUTLET
		I	CW	CW	OUTLET	INLET
		I	CW	CW	OUTLET	INLET

75000 RPM WITH 80° CONTROL
WITH INTERNAL CARTRIDGE
UNISON ROTATION RAE = 4 SOLID MTR

INSTALLATION DRAWING









VIEW A-A



NOTES:
 1. THIS DRAWING IS FOR INFORMATION PURPOSES ONLY. PLEASE REFER TO THE APPROPRIATE KTA PUMP INSTALLATION MANUAL FOR THE APPROPRIATE KTA PUMP INSTALLATION.
 2. SEE THE APPROPRIATE KTA PUMP INSTALLATION MANUAL FOR THE APPROPRIATE KTA PUMP CONTROLS.
 3. REFER TO KTA PUMP ROTARY VALVE CONTROL SYSTEMS FOR THE APPROPRIATE KTA PUMP ROTARY VALVE CONTROL SYSTEM.
 4. REFER TO KTA PUMP ROTARY VALVE CONTROL SYSTEMS FOR THE APPROPRIATE KTA PUMP ROTARY VALVE CONTROL SYSTEM.
 5. REFER TO KTA PUMP ROTARY VALVE CONTROL SYSTEMS FOR THE APPROPRIATE KTA PUMP ROTARY VALVE CONTROL SYSTEM.

B- CONTROL MFG POSITION					
CONTROL OPTION	PUMP PACKAGE	PORT	VALVE ROTATOR	PORT	PORT
DC	DC	IN	VALVE	OUTLET	
DC	DC	IN	VALVE	OUTLET	
DC	DC	IN	VALVE	OUTLET	

PUMP WITH ELECTRONIC CONTROL AND COMPENSATOR
SHUT OFF & WITH FEEDBACK POTENTIOMETER
www.ktadarmahydraulic.com
23-8828








B- CONTROL MFG. POSITION						
OUTLET PORTS	FRONT	RAMP	COMPARATOR	PORT POSITION	PORT	PORT
1	12V	COM	1	OUTLET	OUTLET	OUTLET
2	PMP	COM	2	OUTLET	OUTLET	OUTLET
3	IN	COM	3	OUTLET	OUTLET	OUTLET
4	COM	COM	4	OUTLET	OUTLET	OUTLET

NOTE:
1. FOR PUMP AND MOTOR DISASSEMBLY REFER TO PUMP
2. SEE THE APPROPRIATE SERVICE MANUAL FOR
3. PUMP AND MOTOR ASSEMBLY.
4. REFER TO PUMP AND MOTOR ASSEMBLY
5. DIMENSIONS IN PARENTHESES ARE METRIC (IN INCHES).

DISCRIPTION: 23-9923 CONTROL WIND COMPENSATOR,
SERVOVALVE WITH PVT.
1. WXY-23-9923 SERVOVALVE MONITORING
2. 23-9923


NOTES:
 1. PUMP AND MOTOR LINEAR RESONANCE TEST HAS BEEN
 PERFORMED TO ENSURE THAT NO RESONANCE OCCURS.
 2. MAX METALLIC TEMPERATURE CONTROLLED AT 60°C
 3. MAXICRISTAL THERMOCOUPLE (11-120°C)
 4. PUMP AND MOTOR LINEAR RESONANCE TEST HAS BEEN
 PERFORMED TO ENSURE THAT NO RESONANCE OCCURS.
 5. DIMENSIONS IN PARENTHESIS ARE IN MILLIMETERS (MM).



A CONTROL MTC POSITION						
PUMP POSITION	PUMP PACKAGE	PIPE LINE	SOURCE PRESSURE FOR ACTUATE CONTROL VALVE	MANUAL OVERRIDE SHIRT POSITION	PORT A	PORT B
UP	A ¹ Pump	C1	PSV1	PSV1	VALVE	VALVE
DOWN		C2	PSV2	PSV2	VALVE	VALVE
UP	B ² Pump	C3	PSV3	PSV3	VALVE	VALVE
DOWN		C4	PSV4	PSV4	VALVE	VALVE

ROTATOR PUMP WITH INTEGRATED CONTROL
WITH INTERNAL CARTRIDGE
DRIVEN BY ROTATING SHAFT BOLT TYPE
23-0915 | 612


NOTES:
 1. FOR DIMENSIONS & PARTS IDENTIFICATION REFER DRAWINGS
 2. REFER TO KTA PUMP & MOTOR ASSEMBLY DRAWING FOR PUMP & MOTOR
 3. REFER TO KTA CONTROL VALVE DRAWING FOR CONTROL VALVE
 4. REFER TO KTA POSITIONER DRAWING FOR POSITIONER
 5. REFER TO KTA ROTATING JOINT DRAWING FOR ROTATING JOINT
 6. REFER TO KTA HYDRAULIC METER DRAWING FOR HYDRAULIC METER (2 UNITS)



B CONTROL MTG POSITION						
OPTIONAL	PUMP PACKAGE	TYPE	CONTROL PRESSURE	MANUAL OVERRIDE SHAFT ROTATION	PORT	PORT
Std.	Push	100	300	CCW	INLET	OUTLET
	Push	100	300	CCW	OUTLET	INLET
	Push	100	300	CCW	OUTLET	INLET
	Push	100	300	CCW	OUTLET	INLET

ROTATOR PUMP WITH SAE CONTROL
WITH INTERNAL CARTRIDGE
SWIVEL ROTATING SAE 4 PORT MTS
23-8815 - 2 of 2

NOTE:
FOR DIMENSIONAL IDENTIFICATIONS NOT SHOWN
USE THE APPROPRIATE SKETCHES AND CALLOUTS.
TOP EDGE INDICATES LENGTH OF PART NUMBER 234610-
TOP EDGE INDICATES LENGTH OF PART NUMBER 234610-
REFERENCE TO FUNK POSITION BOOK 4 LOC 1415 IS
INVOKED FROM THIS FIELD.








CONTROL MTG POSITION

BY CONTROLLING POSITION						
CONTROLLER POSITION	PUSH PULL KNOB	FOOT SWITCH	SWITCH, POSITION OR STATE, CONTROL, INDEX	LATCHED, UNLATCHED OR POSITION	PORT #	PORT #
None	None	None	None	None	OUTLET	OUTLET
None	None	None	None	None	OUTLET	OUTLET
None	None	None	None	None	OUTLET	OUTLET
None	None	None	None	None	OUTLET	OUTLET

PASS-THRU FLOW WITH "BIO" CONTROL & TX
AMX PUMP WITH INTERNAL CARTRIDGE
"W" NEW ROTATION SAE F-130L™ MFG.

NOTE:


- 1 FOR DIMENSIONS & PORT IDENTIFICATIONS (NOT SHOWN) SEE THE APPROPRIATE PUMP INSTALLATION GUIDE FOR YOUR PUMP TYPE.
- 2 PUMP BASED INSTALLATION (LESS CONTROL VALVE).
- 3 REFERENCE TO PUMP ROTATION, IN COUNTER CLOCKWISE REFERRED FROM DIAFRAM END.
- 4 CONNECTIONS #1-4 REFERRED ARE PRACTICAL UNITS.



A- CONTROL MTG POSITION					
CONTROL OPTION	FLUID FLOW DIRECTION	PORT A OUT	SHIMMING SPACER	MANUAL OVERRIDE SHIMM. INDICATION	PORT C IN
Hyd. Servo	Out	Outlet	None	None	Inlet
Out	Out	None	None	None	None
In	In	None	None	None	None
Hyd. Servo	Out	Outlet	None	None	Inlet

PEAK FOR FWD WITH TBC CONTROL
WITH INTERNAL CARTRIDGE
SWIVEL ROTATION-SAME AS BOAT MOT


23-0020 1 of 2



B. CONTROL MTG POSITION

PCAP OR P305WTH GROW GROW B304
WITH INTERNAL CARTRIDGE
SWYCOM RGT/TH/1454B-F1-BLT-1TG
23-3920 2 p/2

NOTE:
 1. FOR ASSEMBLING & POSITION IDENTIFICATION CROSSES NOT SHOWN.
 SEE THE APPROPRIATE BASIC PLATE INSTRUCTIONS.
 2. PUMP SIDE MOUNTING TIGHTENING TORQUE: 15000 N.M.
 3. REFERENCE TO PUMP ROTATION: FWD. CCW (12.45°)
 REFERRED FROM SHAFT FWD.
 USE REVERSE BY PUMP SIDE (SEE SECTION DRAWINGS).



EXC. OF PSS WITH 90° CONTROL W/
 INTERNAL CAMTRAILLESS REAR DRIVE
 ON "B" MTG. (S15-E-F-3-POLY-MTG.)

23-9935

卷之三



PUMP CONTROL COMBINATIONS

102	2M2 *00	2N2 *00	402	5A2 *00	7D6 *00	8A2 *00	8C2 *00	9A2 *00
104	2M2 *01	2N2 *01	404	5A2 *01	7D6 *01	8A2 *01	8C2 *01	9A2 *01
106	2M2 *02	2N2 *02	406			8A2 *02	8C2 *02	
107	2M2 *03	2N2 *03	407	5A4 *00	7D7 *00	8A2 *03	8C2 *03	9A4 *00
108	2M2 *04	2N2 *04	408	5A4 *01	7D7 *01	8A2 *04		9A4 *01
	2M2 *05	2N2 *05					8C4 *00	
2A2	2M2 *06	2N2 *06	4A2	5A6 *00	7D8 *00	8A4 *00	8C4 *01	9A6 *00
2A4	2M2 *07	2N2 *07	4A4	5A6 *01	7D8 *01	8A4 *01	8C4 *02	9A6 *01
2A6			4A6			8A4 *02	8C4 *03	
2A7	2M4 *00	2N4 *00	4A7	5A7 *00	7F8 *01	8A4 *03		9A7 *00
2A8	2M4 *01	2N4 *01	4A8	5A7 *01	7F7 *01	8A4 *04	8C6 *00	9A7 *01
	2M4 *02	2N4 *02			7F8 *01		8C6 *01	
2H2	2M4 *03	2N4 *03	4B2	5A8 *00		8A6 *00	8C6 *02	9A8 *00
2H4	2M4 *04	2N4 *04	4B4	5A8 *01	7J6 *00	8A6 *01	8C6 *03	9A8 *01
2H6	2M4 *05	2N4 *05	4B6		7J6 *01	8A6 *02		
2H7	2M4 *06	2N4 *06	4B7	5C2 *00		8A6 *03	8C7 *00	9C2 *00
2H8	2M4 *07	2N4 *07	4B8	5C2 *01	7J7 *00	8A6 *04	8C7 *01	9C2 *01
					7J7 *01		8C7 *02	
	2M6 *00	2N6 *00	4C2	5C4 *00		8A7 *00	8C7 *03	9C4 *00
	2M6 *01	2N6 *01	4C4	5C4 *01	7J8 *00	8A7 *01		9C4 *04
	2M6 *02	2N6 *02	4C6		7J8 *01	8A7 *02	8C6 *00	
	2M6 *03	2N6 *03	4C7	5C0 *00		8A7 *03	8C8 *01	9C6 *00
	2M6 *04	2N6 *04	4C8	5C6 *01	7K6 *01	8A7 *04	8C6 *02	9C6 *01
	2M6 *05	2N6 *05			7K7 *01		8C8 *03	
	2M6 *06	2N6 *06		5C7 *00	7K8 *01	8A8 *00		9C7 *00
	2M6 *07	2N6 *07		5C7 *01		8A8 *01		9C7 *01
						8A8 *02		
	2M7 *00	2N7 *00		5C8 *00		8A8 *03		9C8 *00
	2M7 *01	2N7 *01		5C8 *01		8A8 *04		9C8 *01
	2M7 *02	2N7 *02						
	2M7 *03	2N7 *03						
	2M7 *04	2N7 *04						
	2M7 *05	2N7 *05						
	2M7 *06	2N7 *06						
	2M7 *07	2N7 *07						
	2M8 *00	2N8 *00						
	2M8 *01	2N8 *01						
	2M8 *02	2N8 *02						
	2M8 *03	2N8 *03						
	2M8 *04	2N8 *04						
	2M8 *05	2N8 *05						
	2M8 *06	2N8 *06						
	2M8 *07	2N8 *07						

- Unless otherwise specified on purchase order the following **factory setting** will be used:
- Maximum Stop: Full Displacement
- Minimum Stop: Zero Displacement
- Pressure Compensator Override: 5000-psl
- Torque Limiter (***) P6 @ 1800 rpm = 60 hp
 P7 @ 1800 rpm = 72.5 hp
 P8 @ 1800 rpm = 80 hp
 P11 @ 1800 rpm = 110 hp
 P14 @ 1800 rpm = 140 hp
 P24 @ 1800 rpm = 240 hp
 P30 @ 1800 rpm = 300 hp



flow	$m^3/\text{rev} \times 15.837 = \text{gal}/\text{min}$	$\text{cm}^3/\text{rev} \times 0.000102 = \text{m}^3/\text{rev}$
flow	$\text{gpm} \times 3.78 = \text{l/min}$	$\text{l/min} \times 0.02642 = \text{gpm}$
torque	$\text{hp} \times 0.7457 = \text{kW}$	$\text{kW} \times 1.341 = \text{hp}$
pressure	$\text{bar} \times 100000 = \text{psi}$ $\text{bar} \times 10000000 = \text{MPa}$	$\text{psi} \times 14.50 = \text{bar}$ $(\text{psi} \times 0.1450) \times 10^6 = \text{bar} \times 10^6$
weight	$\text{lb} \times 0.4536 = \text{kg}$	$\text{kg} \times 2.205 = \text{lb}$
force	$\text{lb} \times 4.448 = \text{N}$	$\text{N} \times 0.2248 = \text{lb}$
volume	$\text{in}^3 \times 16.387 = \text{cm}^3$	$\text{cm}^3 \times 0.000102 = \text{in}^3$
area	$\text{in}^2 \times 6.452 = \text{cm}^2$	$\text{cm}^2 \times 0.1550 = \text{in}^2$
length	$\text{in} \times 25.4 = \text{mm}$	$\text{mm} \times 0.03937 = \text{in}$
temperature	$1 \text{ degree F} - 32 = \text{C}$ 1.8	$1.8 \times \text{C} + 32 = \text{F}$
velocity	$\text{ft/sec} \times 1.4 = \text{mm/sec}$ $550 \text{ ft/sec} \times 4.23 = 2340 \text{ mm/sec}$	$\text{mm/sec} \times 1.0 = \text{ft/sec}$ $2340 \text{ mm/sec} = 550 \text{ ft/sec}$

FLUID POWER FORMULAS:

Pump output torque	$\text{lb-in} \times 10^6$	$\frac{\text{pressure}(\text{psi}) \times \text{displacement}(\text{in}^3/\text{rev})}{2\pi \times \text{mech. eff.}}$
Pump input power	hp	$\frac{\text{mm} \times (\text{in}^3/\text{rev}) \times (\text{psi})}{38634 \times \text{overall eff.}}$
Pump output flow	$U \times \text{gpm}$	$\frac{\text{mm} \times (\text{in}^3/\text{rev}) \times \text{volumetric eff.}}{23.1}$
Pump motor speed	rpm	$\frac{29.54 \times \text{flow rate}(U \times \text{gpm}) \times \text{volumetric eff.}}{\text{displacement}(\text{in}^3/\text{rev})}$
Pump motor torque	lb-in	$\frac{\text{pressure}(\text{psi}) \times \text{displacement}(\text{in}^3/\text{rev}) \times \text{mech. eff.}}{2\pi}$
Pump motor power	kW	$\frac{\text{hp} \times 0.746(\text{psi}) \times (\text{psi}) \times \text{overall eff.}}{38634}$
Electric		
Pump input torque	lb-in	$\frac{\text{mech. eff.} \times (\text{psi}) \times \text{displacement}(\text{in}^3/\text{rev})}{20\pi \times \text{mech. eff.}}$
Pump input power	kW	$\frac{\text{mm} \times (\text{cm}^3/\text{sec}) \times (\text{psi})}{600000 \times \text{overall eff.}}$
Pump output flow	l/min	$\frac{\text{cm} \times \text{cm}^3/\text{sec} \times \text{volumetric eff.}}{1000}$
Pump motor speed	$\text{rpm}/(1000/\text{min})$	$\frac{1000 \times \text{flow rate}(\text{l/min}) \times \text{volumetric eff.}}{\text{displacement}(\text{cm}^3/\text{sec})}$
Pump motor torque	Nm	$\frac{\text{mech. eff.} \times (\text{psi}) \times \text{displacement}(\text{cm}^3/\text{sec}) \times \text{mech. eff.}}{20\pi}$
Pump motor power	kW	$\frac{\text{mm} \times (\text{cm}^3/\text{sec}) \times (\text{psi}) \times \text{volumetric eff.}}{600000}$

Tel: 023-55882711

Fax: 023-55882710

Fax: 023-55882105

Denison Hydraulics Inc

14249 Industrial Parkway
Marysville, OH 43040 USA

Tel: +1 614-844-3916
Fax: +1 614-844-3738
E-mail:
deniso@denisonhydraulics.com

Call toll-free:**800-551-5956****In North America or
visit**

www.denisonhydraulics.com
**to locate a
Denison representative
nearest you.**

North America**Canada**

Denison Hydraulics Canada Inc
2880 Brighton Road, Unit 1
Markham, ON L3R 5S3, Canada
Tel: +1 905 829-5800
Fax: +1 905 829-5905

Latin America**Mexico, Central America, South America, Caribbean countries**

Denison Hydraulics Inc
7850 NW 146 Street
Suite 312
Miami Lakes, FL 33016, USA
Tel: +1 (305) 362-2246
Fax: +1 (305) 362-2246

Sia Pacific**Australia**

Denison Hydraulics PTY
41-43 St Hilarys Road
P.O. Box 182
Australia NSW 2144, Australia
Tel: +61 (2) 9646 3200
Fax: +61 (2) 9643 1805

Hong Kong

Denison Hydraulics Ltd
Unit 8A, 33/F Cable TV Tower
911 Hoi Shing Road, Tsuen Wan
N.T., Hong Kong
Tel: +852 2498 6381
Fax: +852 2498 6377

Japan

Denison Japan Inc
4-17 Fasilide-Shimamoto
Fumizawa 251-0042, Japan
Tel: +81 (466) 35-3050
Fax: +81 (466) 35-2018

People's Republic of China

Shanghai Denison Hydraulics
Engineering Ltd
Room 501P, No. 881
Shang Yang Road,
Putuo New Area
Shanghai 200010, P.R. China
Tel: +86 21 58205043/734
Fax: +86 21 58205043/734

Singapore

Denison Hydraulics PTE LTD
Blk 401 Ang Mo Kio Ave 10
Unit #07-010, Techplace
Singapore 569928
Tel: +65 288-7840
Fax: +65 288-7847

Taiwan

Denison Hydraulics LTD
#5-1, Ne. 79
Sec. 2 Roosevelt Rd
Taipei, Taiwan, ROC
Tel: +886-2-23645101
Fax: +886-2-23638025

Europe**Austria**

Denison Hydraulics GmbH
Taxisstrasse 10
Hornbergstrasse 68
4981 Pöggstall, Austria
Tel: +43 (7229) 46 87
Fax: +43 (7229) 6 90 92

Belgium

Denison Hydraulics Benelux B.V.
Paseo de la Cava 100
3316 GR Sondika, Holland
Tel: +31 (0) 6243 070
Fax: +31 (0) 6243 070

Denmark

Denison Hydraulics Denmark A/S
Industrikrogen 2
2625 Brondby, Denmark
Tel: +45 (4371) 15 00
Fax: +45 (4371) 15 18

Finland

Denison Likometec OY
Pölläntie 100/22
P.O. Box 116
33721 Tuusula, Finland
Tel: +358 (0) 357 5100
Fax: +358 (0) 357 5111

France

Denison Hydraulics S.A.
La Roche du Bois Blanç
BP 538
18106 Verzot, France
Tel: +33 (2) 48 83 01 20
Fax: +33 (2) 48 75 02 50

Great Britain

Denison Hydraulics UK LTD
Kemmore Road
Walsfield, nr. Industrial Park
Wakefield, WF2 5XE
West Yorkshire, England
Tel: +44 (1924) 826 021
Fax: +44 (1924) 826 146

Germany

Denison Hydraulics GmbH
Auf dem Sand 14
D-40721 Düsseldorf, Germany
Tel: +49 (0) 2103 1940-0
Fax: +49 (0) 2103 1940-558

Italy

Denison Hydraulics Srl
Via Le Europa 68
20090 Casaglia (MI), Italy
Tel: +39 (031) 903301
Fax: +39 (031) 80390694576
Denison Padova Sp. A.
Via Cesare Saldini 15/17
40011 Antignola dell'Emilia
Emilia-Romagna, Italy
Tel: +39 (051) 850161
Fax: +39 (051) 736221

Spain

Denison Hydraulics S.A.
Carriles 1
08027 Barcelona, Spain
Tel: +34 (93) 129 1990
Fax: +34 (93) 211 8507

Sweden

Denison Hydraulics Svenska AB
Södergatan 13
213 77 Malmö, Sweden
Tel: +46 (40) 600 13 00
Fax: +46 (40) 600 13 50

Others**Other European, Middle East, African countries**

Denison Hydraulics S.A.
Avenida Exportadora
14 Route du Bois Blanc
BP 538
18105 Verzot, France
Tel: +33 (2) 48 83 01 20
Fax: +33 (2) 48 53 01 46

For more information, please contact:

DENISON **Hydraulics**

<http://www.denisonhydraulics.com>